






Viper 5 Smart Treadmill


USER MANUAL



 **kinomap**
30 DAY FREE TRIAL
*Terms and conditions apply. Offer can be rescinded at any time.




Find the
Digital Manual
Online



Product may vary slightly from the item pictured due to model upgrades.



**Read all instructions carefully before using this product.
Retain this owner's manual for future reference.**

NOTE:

This manual should not be used to guide your purchasing decision. Your product, and the contents inside its carton, may vary from what is listed in this manual. This manual may also be subject to updates or changes. Updated manuals are available through our website at www.lifespanfitness.com.au



TABLE OF CONTENTS

- I. Important Safety Instructions 03
- II. Important Electrical Information 05
- III. Important Operating Instructions 06
- IV. Assembly Instructions 07
- V. Operation Guide 16
- VI. Maintenance & Care 27
- VII. Exercise Guide 31
- VIII. Exploded Diagram 33
- IX. Parts List 35
- X. Trouble Shooting 37
- XI. Warranty 38
- XII. Hand Pulse Technology 39

I. IMPORTANT SAFETY INSTRUCTIONS

 **WARNING: Read all instructions before using this treadmill.**

It is important your treadmill receives regular maintenance to prolong its useful life. Failing to regularly maintain your treadmill may void your warranty.

 **DANGER**

To reduce the risk of electric shock disconnect your treadmill from the electrical outlet prior to cleaning and/or service work.

DO NOT USE AN EXTENSION CORD:

DO NOT ATTEMPT TO DISABLE THE GROUNDED PLUG BY USING IMPROPER ADAPTERS OR IN ANY WAY MODIFY THE CORD SET.

- Install the treadmill on a flat level surface with access to a 220-240 volt (50/60Hz), grounded outlet.
- Do not operate treadmill on deeply padded, plush or shag carpet. Damage to both carpet and treadmill may result.
- Do not block the rear of the treadmill. Provide a minimum of 1 metre clearance between the rear of the treadmill and any fixed object.
- Place your unit on a solid, level surface when in use.
- When running, make sure the plastic clip is fastened on your clothing. It is for your safety, should you fall or move too far back on the treadmill.
- Keep hands away from all moving parts.
- Never operate the treadmill if it has a damaged power cord or plug. When damaged, these must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Keep the cord away from heated surfaces.
- Do not operate where aerosol spray products are being used or where oxygen is being administered. Sparks from the motor may ignite a highly gaseous environment.
- Never drop or insert any object into any openings.

- The treadmill is intended for in-home use only and is not suitable for commercial environments.
- The pulse sensors are not medical devices. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as exercise aids in determining heart rate trends in general.
- Use the handrails provided; they are for your safety.
- Wear proper shoes. High heels, dress shoes, sandals or bare feet are not suitable for use on your treadmill. Quality athletic shoes are recommended to avoid leg fatigue.
- Before undertaking any type of exercise program, it is recommended that you consult a doctor.
- Injuries to health may result from incorrect or excessive training.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **WARNING:** Heart rate monitoring systems may be inaccurate. If you feel faint stop exercising immediately.
- Children should not be allowed on or around the equipment, even when not in use.
- Children should be supervised to ensure that they do not play with this machine.
- Loose-fitting clothing or jewellery that could become an entanglement hazard should not be worn.
- Training shoes should be worn when using the equipment.
- Equipment must be used on a level and stable surface.
- All fixings should be checked before the equipment is used.
- All literature relating to the use of the equipment should be retained for future reference.
- Recommended operating temperature: 5-40°C.

II. IMPORTANT ELECTRICAL INFORMATION



WARNING!

- Route the power cord away from any moving part of the treadmill including the elevation mechanism and transport wheels.
- **NEVER** remove any cover without first disconnecting AC power.
- **NEVER** expose this treadmill to rain or moisture. This treadmill is not designed for use outdoors, near a pool, or in any other high humidity environment.
- This is a high-power item; please do not share the same outlet with other high-power machines such as, fridges, air conditioning etc. Please choose an outlet exclusively for the machine and make sure the fuse is 10A.

III. IMPORTANT OPERATING INSTRUCTIONS


- Understand that changes in speed and incline do not occur immediately. Set your desired speed on the computer console and release the adjustment key. The computer will obey the command gradually.
- Use caution while participating in other activities while walking on your treadmill, such as watching television, reading, etc. These distractions may cause you to lose balance or stray from walking in the centre of the belt; which may result in serious injury.
- This unit starts with at a very low speed. It is recommended to stand on the side rails and only step on the treadmill as it is moving on a slow speed. This will prolong the life of your motor and run the belt smoothly.
- This unit starts with at a very low speed. It is recommended to stand on the side rails and only step on the treadmill as it is moving on a slow speed. This will prolong the life of your motor and run the belt smoothly.
- Always hold on to handrail while making control changes.
- This machine has a safety key and a red safety button. Pressing the safety button or pulling the safety key will stop the walking belt immediately; the treadmill will shut off and reset.
- Do not use excessive pressure on console control keys. They are precision set to function properly with little finger pressure.
- Replace any defective components immediately. The machine must be kept out of use until repaired.
- Belt wear-in period: all treadmills make a certain type of thumping noise due to the belt riding over the rollers, especially new treadmills. This noise will diminish over time, although may not completely go away. The belt will stretch over time, causing it to ride smoother over the rollers.
- Set up your machine for storage when the machine is not in use to ensure maximum longevity of electrical components via the following steps:
 1. Ensure incline (if applicable) is reset to zero.
 2. Turn off the machine via the red on/off switch located at the back of the motor. If your machine does not have a switch, turn off the machine at the wall power outlet.

IV. ASSEMBLY INSTRUCTIONS



No.	Description	Qty
A	Main Frame	1
B	Console Base	1
C	Left Upright Tube	1
D	Right Upright Tube	1
E24	Power Wire	1
E	Console	1



B-1



STEP 1

Open the carton and remove the items from the packaging.
Place the Treadmill on a flat level surface and check that all parts are present.
Ensure you have enough area to assemble and have assistance when lifting the main frame.



B-2



STEP 2

1. Remove the motor cover screws and set the cover and screws aside for later.
2. On the handlebar, remove the cover C22 from underneath. Set aside for later.
3. Remove the arch shape piece from inside the motor section. This is packaging and not required for use.

B-3





STEP 3


CAUTION: When installing the upright arms ensure not to crush the cables on the part C and mainframe (A).

1. Connect the cable E08 (on part C) and E09 (on main frame A) as pictured in the zoom image. The other end on the E08 comes out from the top of the part C. Place a tape on it or have someone hold onto it so it does not slide back down.
2. Connect part C upright arms to main frame (A) using 3x washers (D18), 3x washers (D19) and 3x bolts (D06). Note the direction of the bolts.
3. Repeat step 2 for part B upright arms.


B-4



B06, S=13, 14, 15 (1x)



B07 5# (1x)



D12 M5*12 (3x)




D17 M6*10 (2x)



STEP 4

1. Place the motor cover (C03) back on top using 3x screws (D12) for the back and 2x screws (D17) for the sides.

B-5




B11 8# (1x)



D06 M10*20 (6x)



D18 $\phi 10$ (6x)



D19 $\phi 10$ (6x)




STEP 5

CAUTION: Be careful not to crush the cables when installing the handlebar panel to the upright arms. Check that cables are perfectly inside the tube.

1. Connect the cables E07 (from handlebar panel) to E08 (from part C), then ensure the cables are inside the tube before mounting the handlebar panel.
2. Secure the handlebar panel to two upright arms using 6x washers (D18), 6x washers (D19) and 6x screws (D06).

B-6



B08 6# (1x)



D10 M8*15 (4x)



D24 ϕ 8 (4x)




D23 ϕ 8 (4x)



STEP 6

1. Install the Display to the handlebars section using 4x washers (D23), 4x washers (D24) and 4x bolts (D10).



B-7



STEP 7

1. Connect the cables are per the following order: E14 to E13, E04 to E05, 2x E10 to 2x E11 and E06 to E07.
2. Securely place all the cables inside before closing the cover C22. Be careful not to crush any cables.
3. Plug in the power cord E24 to the back of treadmill and plug to wall socket. Do not use on a power board or share the socket with a high-powered equipment.

C-1



Moving the Treadmill

WARNING: Treadmill is heavy and will need a capable adult or 2 people to lift and move. Ensure to bend your knees to avoid back injury.


Hold from point K and lift the treadmill until the transportation wheel touch the floor.

Floor Leveler


If your ground is not levelled, level the treadmill using the two floor leveler at the end of the running deck.

V. OPERATION GUIDE

Main Menu Page



Button Control Panel



BUTTON FUNCTIONS

INCLINE -: Press this button to reduce the incline.

INCLINE +: Press this button to increase the incline.

QUICK INCLINE: Press 3, 6, 9 to change incline quickly.

START: Press this button to start the machine.

HOME: Press this button to enter the main menu page.

SPEED -: Press this button to reduce the speed.

SPEED +: Press this button to increase the speed.

QUICK SPEED: Press 3, 6, 9 to change speed quickly.

STOP/PAUSE: Press this button to pause or stop the machine.

RETURN: Press this button to return to the previous page.


DISPLAY ICONS



Displays Username with User profile is selected in Settings page.



Volume - Users can change Media or System volume by pressing this icon. The volume bar will show the following and user can adjust volume by swiping the dot left or right. After 3 seconds it will disappear.



Media Icon (USB) will be greyed out when there is no USB stick plugged into display.



Bluetooth Icon will be greyed out if it is not connected. Users need to connect this at the settings page and ensure their Device Bluetooth is also turned ON.



Wi-Fi Icon will be greyed out if it is not connected. Users need to connect this at the settings page.



Clicking on this icon will take you to the workout dashboard to change the Speed/Incline. Speed ranges from 1.0-20km/h and Incline 0-18 levels.



Displays workout history.



or  **Cooldown Icon.**



Workout Dashboard - Displays the Speed/Incline graph, Keypad for quick Speed/Incline or -/+ icon for Speed/Incline.



Back Button - Returns to previous screen.



Home Button - Returns to Main Screen.

MEDIA HUB

MP3 Connection: Connect your mobile device to the treadmill using the MP3 AUX cord to play music. Use your device's controls to choose songs and adjust the volume.

Bluetooth Music: Connect your mobile device to the treadmill via Bluetooth to play music. Use your device to select songs and control the volume.


2.1 Connect your device through Bluetooth.

2.2 On your mobile device, select "QY-BTSP" from the list of available devices to connect.


2.3 If your mobile device receives a call while connected via Bluetooth, the treadmill's Bluetooth will automatically disconnect. After the call ends, Bluetooth will reconnect, and music playback will resume automatically.

WORKOUT PROGRAMS


1. QUICK START MODE





- Press the Start/Pause button or the Start (on screen) to begin work out after countdown from 3.
- The display will remain in the main menu. To access the work out setting page (**Dashboard**), press the Up/Down arrows (on screen) or . To return back to main menu press the . You can watch videos or play music from **MEDIA** or access the **BROWSER** during your workout. Clicking on other programs, workout history or settings icons on the main menu will display a prompt to ask if you wish to end your current workout.
- Use the Up/Down buttons or from the screen -/+ or keypad to adjust your speed and incline.






- Press Start/Pause button or Pause/Stop (on screen) to pause your workout.




- Display will show a workout summary. You can resume work out by pressing the Start/Pause button or pressing Resume on the display. The speed and incline will continue from previous setting.
- To end workout, first PAUSE the workout then press End Workout on display (in work out summary page) or press and hold the Start/Pause button. The screen will be cleared and return to main menu.
- At any time, User can enter Cooldown mode with the following buttons  or  (Summary screen).

2. COOLDOWN MODE


- Duration of Cooldown mode is 5 minutes.
- Default Cooldown speed is 7, 6, 5 and 4. Incline is 4, 3, 3, 0 and 0. If your current workout speed is under 7, then the starting speed for the Cooldown will begin from the initial workout speed and then follow through to the next Cooldown speed. The same applies for Incline. If User is already at the Minimum Speed and no Incline, the Cooldown will run at the current settings for 5 minutes.
- During your workout (on all programs) you can enter cooldown mode by pressing this button .
- At the work out summary page you can enter cooldown mode by pressing .
- At the end of the workout, you will see a workout summary of your initial workout and Cooldown time will be entered in. .
- To exit the screen, press the Home button or press Start to enter Quick Start.

3. VIRTUAL RUN PROGRAM

Choose from the following virtual run locations: Opera House, Albert Park, Fitzroy Gardens, St Kilda Beach, Werribee Gorge, or Yarra River Trail.




- After selecting a virtual run location, press **START** to begin the workout.
- Press ∇ to hide the running data on the console and enlarge the virtual scene, or \wedge to display it again.
- During the run, you can adjust speed and incline using the Up/Down buttons or on the screen **0.0 0.0**. Pressing the screen \wedge/∇ will change the screen to the Dashboard page. From here you can change speed/incline with the keypad or $-/+$. To return to the scenery screen press \leftarrow .



NOTE: The virtual run speed will adapt to these changes, but the virtual incline will change if there back automatically if there is incline on the virtual scene. For example: If user setting had 1 incline and the scenery comes to an area with a higher incline, the incline setting will revert to scenery incline level.

4. PROGRAMS MODE

You can choose between **Custom Programs** and **Preset Programs**.




4.1. CUSTOM PROGRAMS

Set your preferred workout parameters to personalize your session.

- Maximum segment users can set is 12. Maximum speed at 20km/h and maximum incline at 18 levels.



- Press the [+] to add a custom program.
- Set the **TIME** by pressing the -/+ or press the digit to bring up the keypad. Users can set the time to maximum 100 minutes.
- To edit the segments for Speed/Incline, click on the graph bar for the 1st segment. The greyed-out Speed/Incline will change to white text, and you can edit the speed using the -/+ or the keypad.



- To add more segments, press **ADD**.
- To delete a segment, choose the segment to delete on the graph bar and press **DELETE**.
- Once you have finished your setting. Press **SAVE** or **CANCEL** (if you do not have to save).
- Press the back button to return to the Custom programs or press **START** to start the program.
- Users can still manually change the Speed/Incline settings during workout however it will revert to the settings when it moves on to the next segment.
- At any time during work out you can enter Cooldown mode or Pause/Stop your workout.

4.2. PRESET PROGRAMS

Choose from 24 different preset workout programs.

- On the Preset Programs screen you can view the programs by pressing **VIEW**.
- In the Preview page for the Present program, Users can edit the time for how long the program runs for. Default times are set for each program which and be viewed on the Program list screen.
- To start the program simply choose the program and press **START**.
- Users can still manually change the Speed/Incline settings during workout however it will revert to the settings when it moves on to the next segment.
- At any time during work out you can enter Cooldown mode or Pause/Stop your workout.

PROGRAMS CHART

PROGRAM	INTERVALS	1	2	3	4	5	6	7	8	9	10	11	12
P01 Warm Up	SPEED	4	5	6	6	7	7	7	7	6	6	5	4
	INCLINE	0	1	1	2	2	2	2	2	2	1	1	0
P02 Incline Walk (Beginner)	SPEED	3	3.5	3	3	3.5	3	3	3.5	3	3	3.5	3
	INCLINE	3	3	3	4	4	4	5	5	4	4	3	3
P03 Incline Walk (Intermediate)	SPEED	4.5	5	4.5	4.5	5	4.5	4.5	5	4.5	4.5	5	4.5
	INCLINE	3	3	3	4	5	6	7	7	8	8	3	0
P04 Incline Walk (Advanced)	SPEED	6	6.5	6	6	6.5	6	6	6.5	6	6	6.5	6
	INCLINE	5	5	5	6	7	8	9	9	10	10	5	0
P05 Incline Jog (Beginner)	SPEED	6	6.5	6	6	6.5	6	6	6.5	6	6	6.5	6
	INCLINE	3	3	3	4	4	4	5	5	4	4	3	0
P06 Incline Jog (Intermediate)	SPEED	8	8.5	8	8	8.5	8	8	8.5	8	8	8.5	8
	INCLINE	3	3	3	4	5	6	7	7	8	8	3	0
P07 Incline Jog (Advanced)	SPEED	10	10.5	10	10	10.5	10	10	10.5	10	10	10.5	10
	INCLINE	5	5	5	6	7	8	9	9	10	10	5	0
P08 HIIT Speed Only (Beginner)	SPEED	5	7	5	7	5	7	5	7	5	7	5	5
	INCLINE	0	0	0	0	0	0	0	0	0	0	0	0
P09 HIIT Speed Only (Intermediate)	SPEED	5.5	8	5.5	8	5.5	8	5.5	8	5.5	8	5.5	5.5
	INCLINE	0	0	0	0	0	0	0	0	0	0	0	0
P10 HIIT Speed Only (Advanced)	SPEED	6	12	6	12	6	12	6	12	6	12	6	6
	INCLINE	0	0	0	0	0	0	0	0	0	0	0	0
P11 HIIT Speed and Incline (Beginner)	SPEED	5	7	5	7	5	7	5	7	5	7	5	5
	INCLINE	4	8	4	8	4	8	4	8	4	8	4	4
P12 HIIT Speed and Incline (Intermediate)	SPEED	5.5	8	5.5	8	5.5	8	5.5	8	5.5	8	5.5	5.5
	INCLINE	4	8	4	8	4	8	4	8	4	8	4	4
P13 HIIT Speed and Incline (Advanced)	SPEED	6	9	6	9	6	9	6	9	6	9	6	6
	INCLINE	5	9	5	9	5	9	5	9	5	9	5	5
P14 Hill Climb (Beginner)	SPEED	6	6	6	5.5	5.5	5.5	5	5	5	4	4	4
	INCLINE	0	2	4	6	7	8	9	10	11	12	13	3
P15 Hill Climb (Intermediate)	SPEED	7	7	7	6.5	6.5	6.5	6	6	6	5	5	5
	INCLINE	1	3	5	7	8	9	10	11	12	13	14	4

PROGRAM	INTERVALS	1	2	3	4	5	6	7	8	9	10	11	12
P16 Hill Climb (Advanced)	SPEED	8	8	8	7.5	7.5	7.5	7	7	7	6	6	6
	INCLINE	2	4	6	8	9	10	11	12	13	14	15	5
P17 Leg Burner	SPEED	5	5	5	6	6	6	5	5	5	6	6	6
	INCLINE	0	6	8	10	12	12	0	6	8	10	12	12
P18 Trail Walk	SPEED	5	5	4	3	3	6	6	4	3	3	4	4
	INCLINE	2	4	3	5	6	1	1	3	5	7	4	4
P19 Steep Trail Walk	SPEED	5	5	4	3	3	6	6	4	3	3	4	4
	INCLINE	7	9	8	10	11	6	6	8	10	12	9	9
P20 Energy Burst	SPEED	4	4	5	6	8	10	10	12	12	8	5	4
	INCLINE	0	2	3	3	2	2	2	2	2	2	3	0
P21 Track Sprint	SPEED	5	6	8	10	12	12	6	8	10	12	12	5
	INCLINE	0	0	0	0	0	0	0	0	0	0	0	0
P22 Over The Hills	SPEED	5	6	4	8	10	5	5	6	4	8	10	5
	INCLINE	5	4	6	2	0	5	5	4	6	2	0	5
P23 Fast Slow	SPEED	6	10	12	10	8	8	6	10	12	10	8	8
	INCLINE	4	0	0	0	2	2	4	0	0	0	2	2
P24 Walk In the Park	SPEED	3	3	3	4	4	5	5	4	5	5	4	3
	INCLINE	0	1	2	1	2	2	0	1	2	1	2	0

5. HEART RATE CONTROL (HRC) PROGRAMS

To use this program, Users must hold onto the pulse handlebars or wireless heart rate strap (**not included with the machine**). Frequency for Wireless strap will need to be 5.3khz to connect with display.

Choose from four different heart rate programs:

CONSTANT HEART RATE CONTROL WITH SPEED CONTROL


CONSTANT HEART RATE CONTROL WITH INCLINE CONTROL

- Speed/Incline is controlled by BPM setting.
- Maximum Incline 18 levels and Speed 20km/h.

HEART RATE RANGE WITH SPEED CONTROL

HEART RATE RANGE WITH INCLINE CONTROL

- Speed/Incline is controlled by Min-Max BPM setting.
- Maximum Incline 18 levels and Speed 20km/h.



5.1. USING THE CONTANT HEART RANGE CONTROL WITH SPEED/INCLINE

- Set your preferred TIME and BPM, and your AGE for exercise. Maximum BPM is 180.
- Press START to begin.
- User will enter a WARM-UP period for 3mins. Speed is automatically set 4, 5, 6 and Incline 1, 2, and 3.
- After warmup ends, HRC program will begin. Speed/Incline will change according to the BPM setting.
- Cooldown can be used at any time during workout or at the work out summary page using the Cooldown icons on screen.


5.2. USING THE HEART RATE RANGE WITH SPEED/INCLINE

- Set your preferred TIME and Min. BPM/BPM (Max), and your AGE for exercise. Maximum BPM is 180.
- Press START to begin.
- User will enter a WARM-UP period for 3mins. Speed is automatically set 4, 5, 6 and Incline automatically set at 1, 2, and 3.
- After warmup ends, HRC program will begin. Speed/Incline will change according to the BPM setting range.
- Cooldown can be used at any time during workout or at the work out summary page using the Cooldown icons on screen.

6. WORKOUT TARGETS



Choose from the following workout targets: Target Time, Target Distance and Target Calories.

- Exercise workout will count down from set TIME/ DISTANCE (KM)/ CALORIES. Users can manually adjust Speed/Incline via display icons or Up/Down buttons. At any time during the workout, users can enter Cooldown mode or via the work out summary page using the Cooldown icons.
- Users can set Maximum as 100 minutes for TIME, 100km for Distance and 1000 Calories.




7. BROWSER

Browser allows access to entertainment via Browser or APP. Requires Wi-Fi to be connected and your own subscription login to the following APPS: Netflix, Binge, Prime Video, Kayo and Spotify.


User can make the browser full screen by pressing the  icon to hide the bottom control icons. Press  to make them reappear.

Videos on Web Browser

When a video is played on website browser, a volume icon  will appear on the bottom right corner for volume adjustments of the video.


8. MEDIA



Plug your USB flash drive to the USB Slot. Playback only supports music (MP3), and video playback (MP4) saved on USB flash drive. Insertion of any other device to this port may cause error to the display.







Music (USB)

Users can select the music by tapping on the name.

The following controls for the music bar (from left to right) are Rewind 15 seconds, Back to previous song, Pause/Play, Skip to next music, Fast forward 15 seconds and Shuffle. 

- After the first song is finished it will play the next song. When Shuffle is chosen the music will play at random order.
- Press the same icon and it will change to . This icon will loop repeat the same music.
- Press the same icon again and it will change to . This icon will play your music in the order of the file. The cycle will repeat back to Shuffle, Repeat and In Order icon.

Video (USB)

- When playing a video, you can go to full screen mode by pressing the square icon. The bottom control icon will disappear.
- To bring up the bottom control icons press the . The video control icons (Skip, Pause, Fullscreen etc.) won't be visible until you tap on the video.
- At any time during workout, you can go to the workout dashboard using the following icons:  or  (press the  while the video is playing. To return to the video screen press the back arrow icon.
- Pressing the back arrow in the video screen will end the video.

9. WORKOUT HISTORY

- Displays previously used workout programs.
- Users can quickly start previously used work out program.

NOTE: Quick start programs are not saved for the setting of Speed/Incline. Please use Custom Programs if you wish to have a user program made.

10. SETTINGS

1. **User Settings:** Add user profile name, age, weight, gender and height. To delete user profile, press the "...".

2. Connectivity:

- **USB:** Plug in your USB and this will automatically show the files in MEDIA.
- **Bluetooth:** Turns on/off Bluetooth setting. Ensure to have your device Bluetooth turned on then pair with the treadmill display.

3. **Wi-Fi Settings:** Turns On/Off Wi-Fi. Choose your Wi-Fi and enter Wi-Fi Password. To disconnect click on the Wi-Fi then "Forget".

4. System Settings:

- **Time and Date:** Sets time and date.
- **Screen Settings:** Changes brightness of the screen.
- **Third Party App Data Reset:** Clears app Data and Cache.
- **System Reset:** Resets the system to initial factory settings.
- **About:** Shows current system version.

5. **Updates:** Updates display software.

NOTE: During update you will not be able to use or turn off treadmill until update is completed. Once the update is completed, turn off the power switch and turn it back on.

11. START//STOP

Press this button to start, pause or stop the machine.

SAFETY KEY FUNCTION

Clip the safety key to your clothing. If you are going too fast, pull the cord and the safety stop will activate. A warning prompt will be displayed. To remove the prompt, press the safety key again and your display will resume to normal operation.

LUBRICATION REMINDER FEATURE

This machine has a lubrication reminder function. After every total running distance of 300km, your treadmill needs to be maintained with oil. The system will have a reminder prompt on the display to perform lubrication to the belt.

PULSE SENSOR HANDLEBARS

When holding the hand pulse sensor with two hands, the pulse window will show your heart rate after 5 seconds.

To get the heartrate more correct, please test when the machine is stopped, and holding the hand pulse more than 30 seconds. The pulse sensors are not 100% accurate and is not to be used as a medical device.

POWER SAVING FEATURE

The machine includes an energy-saving function. When in standby mode, if no operation is detected for 10 minutes, the power-saving mode will activate, and the display will turn off. To reactivate the display, simply press any button.

POWER ON (I) AND POWER OFF (O)

Users can turn the power off from the back switch. We recommend switching it off if it is not being used for a while. This will help prolong the control board's life.

CAUTION:

1. We recommend that you maintain a slow speed at the beginning of a session and hold on to the handrails until you become comfortable and familiar with the treadmill.
2. Attach the magnet end of the safety pulling rope to the computer and attach the clip of the safety pulling rope to your clothing.
3. To end your workout safely, press the STOP button or pull out the safety pulling rope, then the treadmill will stop immediately.

VI. MAINTENANCE & CARE

General cleaning will help prolong the life and performance of your treadmill. Keep the unit clean and maintained by dusting the components on a regular basis. Clean both sides of the running belt to prevent dust from accumulating underneath the belt. Keep your running shoes clean so that dirt from your shoes does not wear out the running board and belt. Clean the surface of the running belt with a clean damp cloth.

- To better maintain the treadmill and prolong its life it is suggested that the machine be powered off for 10 minutes every 2 hours and fully powered off whenever not in use.
- A loose Running Belt will result in the runner sliding off when running, while too tight of a Running Belt will result in decrease to the motors performance and also create more friction between the roller and running belts. The most suitable tightness for the belts is pulled out 50-75mm from the Running Board.

1. GENERAL CLEANING

- Use a soft, damp cloth to wipe the edge of the belt and the area between the belt edge and frame. A mild soap and water solution along with a nylon scrub brush will clean the top of the textured belt. This task should be done once a month. Allow to dry before using.
- On a monthly basis, vacuum underneath your treadmill to prevent dust build up. Once a year, you should remove the black motor shield and vacuum out dirt that may accumulate.

2. GENERAL CARE

- Check parts for wear before use.
- Pay particular attention to the fixing knobs and make sure they are tight.
- Always replace the mat if worn and any other defective parts.
- If in doubt do not use the treadmill and contact us.

! **Take care to protect carpets and floor** in case of leakages. This product is a machine that contains moving parts which have been greased/lubricated and could leak.

3. BELT/DECK/ROLLER LUBRICATION


The mat/deck friction may play a major role in the function and life of your treadmill and that is why we recommend you constantly lubricate this friction point to prolong the useful life of your treadmill. You should apply lubrication after approximately the first 30 hours of operation.

We recommend lubrication of the deck according to the following timetable:

- Light use (less than 3 hours per week) every 6 months.
- Medium use (3-5 hours a week) every 3 months.
- Heavy use (more than 5 hours per week) every 2 months.

See below procedures for lubricating:

1. Raise the belt up on one side and apply lubricant to the running deck. Use a rag to thoroughly wipe the lubricant over the running deck. Repeat this process for the other side.
2. The moving parts should turn freely and quietly. Abnormality of moving parts will affect the safety of the equipment. Inspect and tighten bolts regularly.
3. To better maintain the treadmill and prolong its lifespan, it is suggested that maintenance be done on a regular basis.



Video Tutorial Available at: <http://youtu.be/cP9NtFHfWlc>

Lifespan Fitness YouTube Channel: <http://www.youtube.com/user/treadmillsvideos>

4. HOW TO CHECK THE RUNNING MAT FOR PROPER LUBRICATION

1. Disconnect the main power supply.
2. Fold the treadmill up into the storage position.
3. Feel the underside surface of the running mat.

If the surface is slick when touched, then no further lubrication is needed.

If the surface is dry to the touch, apply a suitable silicone lubricant.

! We recommend that you use a silicone based spray to lubricate your treadmill. This can be purchased directly from us or any hardware store.


Video Tutorial Available at: <http://youtu.be/cP9NtFHfWlc>

Lifespan Fitness YouTube Channel: <http://www.youtube.com/user/treadmillsvideos>


5. CENTERING THE RUNNING BELT

Place the treadmill on level ground and set it at 6-8kph to check if the Running Belt drifts.


1. If the Running Belt moves to the right, turn the adjusting bolt on the right side $\frac{1}{4}$ turn clockwise, then turn the left adjustment bolt $\frac{1}{4}$ turn counter clockwise. If the belt does not move, repeat this step until it centers. Refer to figure A.




2. If the Running Belt moves to the left, turn the adjusting bolts on the left side $\frac{1}{4}$ of a turn clockwise, then turn the right adjustment bolt $\frac{1}{4}$ turn counterclockwise. If the belt does not move, repeat this step until it centers. Refer to figure B.



3. Over time the Running Belt will loosen. To tighten the belt, turn the Left & Right-side adjustment bolts one full turn clockwise, check the tension of the belt. Continue this process until belt is at the correct tension. Make sure to adjust both sides equally to ensure correct belt alignment. Refer to figure C.






! NOTE:

When properly tightened, you should be able to peel the very edge of the side of the belt up approximately 2 inches. However, this is a rough reference and not all treadmills are the same. Some treadmills that have longer belts may give different measurements for correct belt tightness.

Simply, if the belt begins to slip during use, this is an indication that the belt still needs tightening.



Video Tutorial Available at: <http://youtu.be/vllsamTSvva>

Lifespan Fitness YouTube Channel: <http://www.youtube.com/user/treadmillsvideos>

VII. EXERCISE GUIDE

! PLEASE NOTE:


Before beginning any exercise program, consult your physician. This is important especially if you are over the age of 45 or individuals with pre-existing health problems.

The pulse sensors are not medical devices. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as an exercise aid in determining heart rate trends in general.

Exercising is great way to control your weight, improving your fitness and reduce the effect of aging and stress. The key to success is to make exercise a regular and enjoyable part of your everyday life.

The condition of your heart and lungs and how efficient they are in delivering oxygen via your blood to your muscles is an important factor to your fitness. Your muscles use this oxygen to provide enough energy for daily activity. This is called aerobic activity. When you are fit, your heart will not have to work so hard. It will pump a lot fewer times per minute, reducing the wear and tear of your heart.

So as you can see, the fitter you are, the healthier and greater you will feel.



WARM UP


Start each workout with 5 to 10 minutes of stretching and some light exercises. A proper warm-up increases your body temperature, heart rate and circulation in preparation for exercise. Ease into your exercise.

After warming up, increase the intensity to your desired exercise program. Be sure to maintain your intensity for maximum performance. Breathe regularly and deeply as you exercise.

COOL DOWN

Finish each workout with a light jog or walk for at least 1 minute. Then complete 5 to 10 minutes of stretching to cool down. This will increase the flexibility of your muscles and will help prevent post-exercise problems.


WORKOUT GUIDELINES



⚠ This is how your pulse should behave during general fitness exercise. Remember to warm up and cool down for a few minutes.

The most important factor here is the amount of effort you put in. The harder and longer you work, the more calories you will burn.

VIII. EXPLODED DIAGRAM



IX. PARTS LIST

No.	Description	Specs	Qty
A01	Main Frame		1
A02	Incline Bracket		1
A03	Console Base Bracket		1
A04	Panel Connecting Bracket		1
A05	Left Upright Tube		1
A06	Right Upright Tube		1
A08	Motor Fixed Base		1
B01	Front Roller		1
B02	Back Roller		1
B03	Cardan Joint Screw		2
B04	Wheel Sleeve		2
B05	Spring 1		4
B06	Wrench w/ Screwdriver	S=13,14, 15	1
B07	5# Allen Wrench	5mm	1
B08	6# Allen Wrench	6mm	1
B09	Pulse Steel Plate		4
B10	Spring		1
B11	8# Allen Wrench	8mm	1
B12	Screen Fixing Plate		1
B13	Big Gasket		2
C01	Panel Top Cover		1
C02	Panel Bottom Cover		1
C03	Motor Top Cover		1
C04	Back-end Cover		1
C05	Left Side Rail		1
C06	Right Side Rail		1
C07	Running Belt		1
C08	Universal Mats		2
C09	Mats Cover		2
C10	Elliptical Cushion		4
C11	Cushion		4
C12	Wheel		2
C13	Motor Belt		1

No.	Description	Specs	Qty
C14	Foot Pad		2
C15	Plastic Side Rail Gasket		6
C16	Plastic Gasket		2
C18	Console Top Cover		1
C19	Emergency Button		1
C20	Button Holder		1
C21	Console Bottom Cover		1
C22	Console Screw Cover		1
C23	Console Support Top Cover		1
C24	Console Support Bottom Cover		1
C25	Left Handlebar		1
C26	Right Handlebar		1
C27	Left Handlebar Decoration Ring		1
C28	Right Handlebar Decoration Ring		1
C29	Motor Left Insulating Sleeve		1
C30	Motor Right Insulating Sleeve		1
C31	EVA Pad		1
D01	Nut	M8	13
D02	Nut	M10	4
D03	Bolt	M10*65	1
D04	Bolt	M10*45	3
D05	Bolt	M8*15	4
D06	Bolt	M10*20	12
D07	Bolt	M10*20	2
D08	Bolt	M8*65	2
D09	Bolt	M8*60	1
D10	Bolt	M8*15	8
D11	Bolt	M8*25	4
D12	Bolt	M5*12	3
D13	Screw	ST4.2*12	37
D14	Screw	ST4.2*20	6

No.	Description	Specs	Qty
D15	Screw	ST4.2*25	8
D16	Screw	ST2.9*8	18
D17	Bolt	M6*10	2
D18	Flat Washer	10	14
D19	Spring Washer	10	14
D20	Lock Washer	8	11
D21	Lock Washer	10	2
D22	Flat Washer	8	17
D23	Spring Washer	8	8
D24	Bolt	M5*16	4
D25	Bolt	M5*12	2
D26	Spring Washer	5/65Mn	2
D27	Lock Washer	5	2
D28	Bolt	M8*40	4
D29	Screw	ST4.2*12	2
D30	Screw	ST2.9*8	4
D31	Bolt	M8*50	1
D32	Bolt	M5*10	1
D33	Bolt	M5*8	1
D34	Screw	ST4.2*20	1
E01	Console		1
E02	Control Board		1
E03	Touch Button Board		1
E04	Touch Button Top Signal Wire		1

No.	Description	Specs	Qty
E05	Touch Button Bottom Signal Wire		1
E06	Console Top Signal Wire		1
E07	Console Middle Signal Wire 1		1
E08	Console Middle Signal Wire 2		1
E09	Console Bottom Signal Wire		1
E10	Hand Pulse Top Signal Wire		1
E11	Hand Pulse Bottom Signal Wire		2
E12	Microswitch		1
E13	Switch Top Signal Wire		1
E14	Switch Bottom Signal Wire		1
E22	Magnetic Ring		1
E23	Magnetic Core		1
E24	Power Wire		1
E25	AC Signal Wire	200 Blue	1
E26	AC Signal Wire	350 Blue	2
E27	AC Signal Wire	350 Brown	2
E28	Ground Wire	350	2
E29	Power Socket		1
E30	Switch on-off		1
E31	Overload Protector		1
E33	Safety Key Clip		1
G01	Speaker		2
G02	Screw		8

OPTIONAL PARTS LIST

No.	Description	Specs	Qty
H01	USB Module		1
H02	USB Connecting Wire		1
H03	Screw	ST2.9*8	2
K1	Wireless Charging Board Wire		1
K2	Wireless Charging Bottom Board Wire		1

No.	Description	Specs	Qty
K2	Wireless Charging Board		4
K3	Screw	ST2.9*8	1
K4	Wireless Charging Base		1

X. TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SUGGESTED ACTION
Treadmill will not start	Not plugged in	Plug cord into outlet
	Safety Key not inserted	Insert Safety Key
Running belt not centered	Running belt tension is not correct on the left or right sides of the running board	Tighten the adjustment bolts on both the left and right sides of the rear roller
Computer not working	Wires from the computer and bottom control board not properly connected.	Check and secure the wire connections between the computer and the control board
	Transformer is damaged	If the transformer is damaged, contact customer service
E01: Message failure	Wires from the console and bottom control board are not properly connected	<ul style="list-style-type: none"> • Check and secure the wire connections between the console and control board • Replace any punctured or damaged wires • If unresolved, replace the control board • Inspect the console and replace it if damaged
E03: No speed sensor signal	Speed sensor signal cannot be received by the control board	<ul style="list-style-type: none"> • Check if the speed sensor port is securely connected; reconnect if loose • Inspect the control board for damage and replace if necessary • Check the motor for damage and replace if necessary
E05: Current Overload Protection (Self-Protecting System)	<ul style="list-style-type: none"> • Incoming voltage is too low or too high. • Control board is damaged. • A moving part of the treadmill is stuck, causing the motor to malfunction. 	<ul style="list-style-type: none"> • Restart the treadmill. • Verify the incoming voltage is correct. • Inspect and ensure all moving parts operate smoothly. • Check the motor for unusual noises or a burning smell; replace if necessary. • Inspect and replace the control board if damaged. • Lubricate the treadmill.
E08: IPM Module Short Circuit	IPM module failure.	Replace the inverter with a new one.
E09: Over Temperature	Treadmill has overheated.	Allow the treadmill to cool to a normal temperature before resuming use.

XI. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au.

Please visit our website to view our full warranty terms and conditions:
<http://www.lifespanfitness.com.au/warranty-repairs>

WARRANTY AND SUPPORT

Any claim against this warranty must be made through your original place of purchase. Proof of purchase is required before a warranty claim may be processed.

If you have purchased this product from the Official Lifespan Fitness website, please visit <https://lifespanfitness.com.au/warranty-form>

For support outside of warranty, if you wish to purchase replacement parts or request a repair or service, please visit <https://lifespanfitness.com.au/warranty-form> and fill in our Repair/Service Request Form or Parts Purchase Form.

Scan this QR code with your device to go to lifespanfitness.com.au/warranty-form



XII. HAND PULSE TECHNOLOGY

This product comes equipped with hand pulse sensors which are used to pick up tiny EKG/ECG signals that run through the body when your heart beats. These electrical EKG/ECG signals are very small and that they must be amplified 1000 times to make the signal useful for the computer to display your pulse.

To ensure proper operation:

- The user must maintain good, consistent contact on all four sensors.
- The users skin cannot be too dry or too wet.

Other factors that could affect the reading:

- Change of grip on the sensors (during slow pace walking and up to running).
- Tightening of hand muscles will produce small electrical signal.
- Static electricity charges from the air or from walking on the treadmill.

EKG/ECG Sensors may filter through actual EKG/ECG signals and "Noise" factors that may affect the reading. This will cause the pulse reading to be delayed and will take longer to update the display as the heart rate changes. Too much noise will create an incorrect reading. Medical conditions or having no electrical signal in the hands are other factors that may affect pulse readings as well.

These are limitations of hand pulse technology and even the most expensive systems (which can cost upwards of \$3,000) used in hospitals have the same problems. The difference is that a patient in a hospital is not running on a treadmill. Hand pulse technology works well on stationary exercise machines like bikes and even elliptical cross trainers but are not perfect on a treadmill. We offer treadmills with a wireless heart rate receiver which may be a more accurate option.

To test if your hand pulse sensors are working up to specification, hold them while standing on the sidestep rails, not walking, and see if the reading is more in line with what you would expect. This will eliminate the movement and static electricity factors. If your hands are dry, then wet them slightly (saliva works as a great conductor if this doesn't bother you).



WWW.LIFESPANFITNESS.COM.AU