CORTEX® SR-3 SQUAT RACK

USER MANUAL



Product may vary slightly from the item pictured due to model upgrades.



Read all instructions carefully before using this product. Retain this owner's manual for future reference.

NOTE:

This manual may be subject to updates or changes. Up to date manuals are available through our website at www.lifespanfitness.com.au

TABLE OF CONTENTS

I.	Important Safety Instructions	03
II.	Parts List	04
III.	Assembly Instructions	.05
IV.	Exercise Guide	09
٧.	Warranty	11

I. IMPORTANT SAFETY INSTRUCTIONS

/! WARNING: Read all instructions before using this machine.


Please take caution when re-racking your weights. Re-racking with excess forward momentum may cause the rack to topple over

Please keep this manual with you at all times.


- · It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained and used properly. Please note: It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.
- · Before starting any exercise program you should consult your doctor to determine if you have any medical or physical conditions that could put your health and safety at risk, or prevent you from using the equipment properly. Your doctor's advice is essential if you are taking medication that affects your heart rate, blood pressure or cholesterol level.
- Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, and extreme shortness of breath, lightheadedness, dizziness or feelings of nausea. If you do experience any of these symptoms, you should consult your doctor before continuing with your exercise program.
- Keep children and pets away from the equipment. This equipment is designed for adult use only.
- Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 2 meters of free space around it.
- Before using the equipment, check that the nuts and bolts are securely tightened. If you hear any unusual noises coming from the equipment during use and assembly, stop immediately. Do not use the equipment until the problem has been rectified.
- · Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may get caught in the equipment or that may restrict or prevent movement.
- · This equipment is designed for indoor and family use only.
- Care must be taken when lifting or moving the equipment so as not to injure your back.
- Always keep this instruction manual and assembly tools at hand for reference.
- Keep hands away from all moving parts.
- The equipment is not suitable for therapeutic use.

II. PARTS LIST

Part No.	Name	Model	Quantity
1	Tube		2
2	Vertical Tube		2
3	Strengthen Board		2
4	Plate Rest		4
5	Bar Support		2
6	Bar Rest		2
7	Connection Tube		1
8	Strengthen Board	110mm	4
9	Carriage Bolts	M10X65mm	20
10	Nuts	M10	20
11	Washers	M10	20
12	Pull-Up Bar		1
13	Strengthen Board (different hole position)	110mm	2




III. ASSEMBLY INSTRUCTIONS




1. Attach the Tube (#1) to the Vertical Tube(#2). Secure it with:

Secure it with:


- 2 Strengthen Board (#3)
- 1 Strengthen Board (#13)
- 6 Carriage Bolts M10x65mm (#9)
- 6 M10 Nuts (#10)
- 6 Washers Dia10 (#11)



- 1. Plug the Bar Rest (#6) and Bar Support (#5) into the Vertical Tube (#2).
- 2. Plug the Bar (#4) into the Tube (#1).



- 1. Attach the Connection Tube (#7) to the Tube (#1). Secure it with:
 - 2 Strengthen Boards 110mm (#8)
 - 4 Carriage Bolts M10x65mm (#9)
 - 4 M10 Nuts (#10)
 - 4 Washers Φ10 (#11)



1. Attach the Tube (#12) to the Vertical Tube(#2).

Secure it with:

- 2 Strengthen Board (#8)
- 4 Carriage Bolts M10x65mm (#9)
- 4 M10 Nuts (#10)
- 4 Washers Dia10 (#11)

IV. EXERCISE GUIDE

(!) PLEASE NOTE:


Before beginning any exercise program, consult your physician. This is important especially if you are over the age of 45 or individuals with pre-existing health problems.

The pulse sensors are not medical devices. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as an exercise aid in determining heart rate trends in general.

Exercising is great way to control your weight, improving your fitness and reduce the effect of aging and stress. The key to success is to make exercise a regular and enjoyable part of your everyday life.

The condition of your heart and lungs and how efficient they are in delivering oxygen via your blood to your muscles is an important factor to your fitness. Your muscles use this oxygen to provide enough energy for daily activity. This is called aerobic activity. When you are fit, your heart will not have to work so hard. It will pump a lot fewer times per minute, reducing the wear and tear of your heart.

So as you can see, the fitter you are, the healthier and greater you will feel.



WARM UP


Start each workout with 5 to 10 minutes of stretching and some light exercises. A proper warm-up increases your body temperature, heart rate and circulation in preparation for exercise. Ease into your exercise.

After warming up, increase the intensity to your desired exercise program. Be sure to maintain your intensity for maximum performance. Breathe regularly and deeply as you exercise.

COOL DOWN

Finish each workout with a light jog or walk for at least 1 minute. Then complete 5 to 10 minutes of stretching to cool down. This will increase the flexibility of your muscles and will help prevent postexercise problems.

WORKOUT GUIDELINES



This is how your pulse should behave during general fitness exercise. Remember to warm up and cool down for a few minutes.

V. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au.

Please visit our website to view our full warranty terms and conditions: http://www.lifespanfitness.com.au/warranty-repairs

WARRANTY AND SUPPORT

Any claim against this warranty must be made through your original place of purchase. Proof of purchase is required before a warranty claim may be processed.

If you have purchased this product from the Official Lifespan Fitness website, please visit https://lifespanfitness.com.au/warranty-form

For support outside of warranty, if you wish to purchase replacement parts or request a repair or service, please visit https://lifespanfitness.com.au/warranty-form and fill in our Repair/Service Request Form or Parts Purchase Form.

Scan this QR code with your device to go to lifespanfitness.com.au/warranty-form



