

## ASSEMBLY INSTRUCTIONS

Age Range: 10-36 months

To be retained for future reference.

WARNING! For outdoor domestic use only

WARNING! Adult supervision required at all times.

WARNING! This item is to be assembled and disassembled by an adult.

WARNING! Head or other injuries may result when falling onto hard surfaces.

WARNING! Never place swing over concrete, asphalt, wood or other hard surfaces.

WARNING! Never leave child unattended.

WARNING! Max user weight 25 kg.

WARNING! Not suitable for children under 36 months until fully assembled- small parts-choke hazard.



WARNING! To prevent falls, use restraint system at all times.

WARNING! Not to be used by children over 36 months.

### 1-Location of apparatus

Minimal space in millimetres (mm) to respect between apparatus and structure of portico

| Spaces in millimeter between | Éléments de balancement libres<br>Free balance elements | Éléments semi-flexibles<br>Semi-flexible elements | Dotés de suspentes rigides<br>Endowed with stiff suspentes | Structure adjacente des balançoires<br>Neighbouring Structure of swings |
|------------------------------|---|---|--|---|
| Free balance elements        | 450   | 450   | 450  | 300   |
| Semi-flexible elements       | 450   | 300   | 300  | 300   |
| Endowed with stiff suspentes | 450   | 300   | 300  | 300   |



### 2- Fixation of apparatus on the hook

The location of the hook carbine must be perpendicular in the axis of the beam of the portico, so that the balance of apparatus is correctly made.

The toy must be placed on a level surface at least 2meter from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires.

The toy shall not be installed over concrete, asphalt or any other hard surface.

### 3- Control and Maintenance

Control regularly the state of the elements of suspension. Verify monthly the good tightening of all screws and nuts, and systems of fixation of apparatus, to prevent the falling risks replace all the damaged masks or missing nuts. Remove apparatus during the wintry period to avoid any premature degradation concerning the bad weather, from the slightest appearance of degradation of apparatus, and at least after 24 months of exposure outdoors, replace them by apparatus of the same conception. The change must be more frequent in zones with strong period of sunshine.

### AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at [www.consumerlaw.gov.au](http://www.consumerlaw.gov.au)

Please visit our website to view our full warranty terms and conditions:

<http://www.lifespankids.com.au/Warranty-Policy-Kids>

Please email us at [support@lifespankids.com.au](mailto:support@lifespankids.com.au) for all warranty or support issues.