


ASSEMBLY INSTRUCTION/NOTICE DE MONTAGE/MONTAGENWTIZ/PROSPECTO DE MONTAGE/ISTRUZIONI PER IL MONTAGGIO/組み立て説明書/组装说明书

 **Classic
WORLD**
50562



56 PCS

WARNING:

Assembly by an adult.

A assembler par un adulte.

Das Zusammenbauen sollte durch einen Erwachsenen übernommen werden.


Eljuego debe ser montado por un adulto.

Il montaggio deve essere effettuato da un adulto.


組み立ては大人の方にお願ひ致します。

警告：本产品含有小部件，仅供成人组装及三岁以上小朋友使用。


1 x1




2 x1




3 x1




4 x1




5 x1



6 x1




7 x1




White

8 x1




White


9 x1




10 x1




11 x1




12 x1




13 x1




14 x1




15 x1




16 x1




17 x1




18 x1




19 x1




20 x1




21 x1




22 x1




23 x1




24 x1




25 x1




26 x1



27 x4




28 x5



29 x2




30 x1




31 x1




32 x2




33 x44



34 x5




35 x5



36 x5




37 x5



38 x10




39 x1











40 x28




41 x1









9




10




11




12




13



14



15



16

