


ACTIVEGO

POWERBREAK 8FT SLATE POOL TABLE

USER MANUAL



Find the
Digital Manual
Online



Product may vary slightly from the item pictured due to model upgrades.



**Read all instructions carefully before using this product.
Retain this owner's manual for future reference.**

NOTE:

This manual should not be used to guide your purchasing decision. Your product, and the contents inside its carton, may vary from what is listed in this manual. This manual may also be subject to updates or changes. Updated manuals are available through our website at www.lifespanfitness.com.au



TABLE OF CONTENTS

- I. Care, Maintenance, and Safety Information 03
- II. Parts List 04
- III. Assembly Instructions 06
- IV. Warranty 15

I. CARE, MAINTENANCE, AND SAFETY INFORMATION

Intended Use

This pool table is designed for indoor home use only. Exposure to outdoor elements, such as sunlight or moisture, can damage the table's surface and frame.

Safety Instructions

1. Ensure the table is leveled by adjusting the floor leveler before use.
2. Avoid placing food, drinks, or heavy objects on the playing surface, as spills and weight can damage the felt and impact game quality.
3. Do not sit or stand on the table.

Care and Cleaning

1. Use the supplied brush to dust off the felt playing surface. Avoid using any cleaning agents directly on the felt, as this can degrade the material.
2. Do not use a wet rag on the felt.
3. Do not use abrasive cleaning solutions.
4. Check for loose hardware and re-tighten where necessary.

Storage

Caution: Have 2 or more people to move the table.

When relocating the table, please lift it gently rather than dragging it. Dragging can damage the legs and stability of the table.

II. PARTS LIST

1



5/16 3-1/4"
(8x82mm) Bolt
16pcs.

2



5/16 2-1/2"
(8x63mm) Bolt
8pcs.

3



1/4 2-1/2"
(6x63mm) Bolt
16pcs.

4



5/16 3-1/4"
(8x82mm) Bolt
18pcs.

5



1/4x1-1/4"
(6x32mm) Bolt
12pcs.

6



T3.5x1/2"
(3.5x12mm) Screw
24pcs.

7



T3.5x1/2"
(3.5x25mm) Screw
12pcs.

8



T4x1-3/4"
(4x45mm) Screw
24pcs.

9



1/4"
(6mm) Washer
28pcs.

10



5/16"
(8mm) Washer
24pcs.

11



5/16"
(8mm) Washer
18pcs.

12



5/16"
(8mm) Nut
18pcs.

13



Leg Leveler
4pcs.

14



Allen Key
1pc.

15



Corner Cap-A
2pcs.

16




Corner Cap-B
4pcs.

17



Cloth
1pc.

18



Apron Corner
4pcs.

19



Plastic Bracket
2pcs.

20




Basket-A
2pcs.

21




Basket-B
4pcs.

22



Billiard Balls
1 Set

23



Triangle
1pc.

24




Cue Stick
2pcs.

25




Chalk
2pcs.

26




Brush
1pc.

A




Slate
1 Set

B




Left Leg
2pcs.

C




Right Leg
2pcs.

D




Leg End Panel
2pcs.

E




Leg Side Panel
2pcs.

F




End Support Brace
4pcs.

G




Side Support Brace
2pcs.

H




Side Rail
4pcs.

I




End Rail
2pcs.

J



End Apron
2pcs.

K




Side Apron
4pcs.

TOOL INCLUDED: Staple Gun and Staples

III. ASSEMBLY INSTRUCTIONS

STEP 1

Secure 2x (G) Side Support Brace together with 4x (F) End Support Brace in the middle as pictured using #1 8x82mm Bolt - 16 qty and #1 8x82mm Bolt - 16 qty.



1



(8x82mm) Bolt
16pcs.


10



(8mm) Washer
16pcs.

STEP 2

Secure 2x (B) Left Leg on the on the left side and the 2x (C) Right Leg on the right side and using #2 8x63mm Bolt - 8 qty and #10 8mm Washer - 8 qty.



2



(8x63mm) Bolt
8pcs.


10



(8mm) Washer
8pcs.

STEP 3

Secure 2x (D) Leg End Panel in between the 2x legs using #3 6x63mm Bolt - 8 qty and #9 6mm Washer - 8 qty.



3



(6x63mm) Bolt
8pcs.


9



(6mm) Washer
8pcs.

STEP 4

1. Place the #13 Floor Leveler - 4 qty on the bottom of the legs.
2. Install 2x (E) Leg Side Panel on the legs as pictured using #3 6x63mm Bolt - 8 qty and #9 6mm Washer - 8 qty.
3. With assistance, turn the table over to the floor levelers. Adjust the leveler if the ground is uneven.



3



(6x63mm) Bolt
8pcs.

9



(6mm) Washer
8pcs.


13



Floor Leveler
4pcs.

STEP 5

Layout the parts as pictured for (A1), (A2) and (A3) Slate.




STEP 6

1. Lay the #17 Cloth onto the Slate evenly. Mark out the holes and cut the holes.


TIP: You can use some masking tape to hold the cloth in place so it does not move, however make sure to remove this at the end.

2. Once you have the cloth evenly placed, use the staple gun to fix six holes in the wooden board under the Slate.



STEP 7

Place the 18x #4 8x82mm Bolt on the back of the table and align to (H1 & H2) Side Panels and (I) End Rails, lock with #11 8mm Washer - 18 qty and #12 8mm Nut - 18 qty.



4



(8x82mm) Bolt
18pcs.

11



(8mm) Washer
18pcs.


12



(8mm) Nut
18pcs.

STEP 8

Secure the 2x #15 Corner Cap-A and 4x #16 Corner Cap-B as pictured using #5 6x32mm Bolt - 12 qty and #9 6mm Washer - 12 qty.



5



(6x32mm) Bolt
12pcs.


9



(6mm) Washer
12pcs.

STEP 9

1. Attach 4x #18 Apron Corner to the 2x (J) End Apron using #6 3.5x12mm Screws - 12 qty.
2. Attach 2x (J) End Apron to the table ends using #8 4x45mm Screws - 6 qty.
2. Join 2x (K) Side Apron together using #19 Plastic Bracket and slot them into the gap on #18 Apron Corner. Repeat for the other side.



6



(3.5x12mm) Screws
12pcs.


8



(4x45mm) Screws
6pcs.

STEP 10

1. Secure the (K) Side Apron using #8 4x45mm Screws - 16 qty.
2. Insert the Baskets #20 and #21 into the respective holes as pictured. Secure 4x #21 Basket-B to each corner of the table and #20 Basket-A to the middle of the table, using #7 3.5x25mm Screws - 12 qty.



7



(3.5x25mm) Screws
12pcs.

8



(4x45mm) Screws
16pcs.

IV. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au.

Please visit our website to view our full warranty terms and conditions:
<http://www.lifespanfitness.com.au/warranty-repairs>

WARRANTY AND SUPPORT

Any claim against this warranty must be made through your original place of purchase. Proof of purchase is required before a warranty claim may be processed.

If you have purchased this product from the Official Lifespan Fitness website, please visit <https://lifespanfitness.com.au/warranty-form>

For support outside of warranty, if you wish to purchase replacement parts or request a repair or service, please visit <https://lifespanfitness.com.au/warranty-form> and fill in our Repair/Service Request Form or Parts Purchase Form.

Scan this QR code with your device to go to lifespanfitness.com.au/warranty-form



ACTIVEGO

WWW.ACTIVEGO.COM.AU