




Electric Air Pump

USER MANUAL

Find the
Digital Manual
Online



PUMP SAFETY & OPERATING INSTRUCTIONS



I. IMPORTANT INFORMATION

- Power supply: AC 220-240V only.
- This is a high-volume, low-pressure pump, designed for inflating/deflating items such as air mattresses, inflatable boats, and similar products.
- Not suitable for continuous use. Operating longer than 15 minutes may cause overheating. Allow the unit to cool for at least 30 minutes before reuse.

Usage Safety

- This product is not intended for use by children or persons with reduced physical, sensory, or mental capabilities, unless supervised or instructed by a responsible adult.

- Children must be supervised at all times and must not play with the appliance.
- Ensure the inflation/deflation ports remain unobstructed during operation.
- Always use the correct nozzle adaptor for the valve size to ensure efficient performance.


Disposal

- Do not dispose of this product with general household waste.
- Follow local regulations for electrical waste recycling to prevent environmental harm.

II. WARNING

- Do not connect the unit to a damaged power source or extension cord. If the cord is damaged, contact a qualified technician.
- Follow all instructions on the inflatable item. Do not exceed recommended pressure levels.
- Never leave the pump unattended while in use.
- Do not operate the pump in wet or damp conditions.
- Prevent sand, dirt, or debris from entering the air ports.
- Never look into or direct airflow toward your face or eyes during operation.
- Do not insert fingers or objects into the air ports.
- Store indoors only.
- The power cord is non-replaceable. If damaged, discontinue use and dispose of the unit.
- Allow the unit to cool down before cleaning or storing.
- Clean with a dry or slightly damp cloth only. Do not immerse in water.
- Do not expose the unit, plug, or cord to liquids.
- This product is a handheld electric air pump.

III. TO INFLATE ITEMS




1. Connect the plug to a 220-240V power outlet.
2. Attach the appropriate nozzle to the inflation port.
3. Insert the nozzle securely into the valve of the inflatable item.
4. Turn the switch to "ON" (-) to begin inflating.
5. Turn the switch to "OFF" (O) once the desired firmness is reached.

IMPORTANT NOTES

- Do not block the valve during operation, as this may cause overheating.
- Do not use the deflation port for inflating.
- For large valves (e.g. air beds), connect directly without an adaptor if possible.
- For smaller valves, use the appropriate adaptor for a secure fit.

IV. TO DEFLATE ITEMS



1. Open the valve of the inflatable item.
2. Attach the nozzle to the deflation port.
3. Insert the nozzle into the valve.
4. Switch the unit to "ON" (-) to begin deflation.
5. Switch to "OFF" (O) once deflation is complete.

IMPORTANT NOTES

- Ensure airflow is not obstructed during operation.
- For small valves, gently open the flap valve manually if required.
- For screw-type valves:
 - Unscrew before inflating/deflating
 - Re-secure tightly after use to prevent air leakage