


PT-105 Commercial Chin Up Dip Knee Raise Power Tower

USER MANUAL



Product may vary slightly from the item pictured due to model upgrades.



Read all instructions carefully before using this product. Retain this owner's manual for future reference.

NOTE

This manual may be subject to updates or changes. Up to date manuals are available through our website at www.lifespanfitness.com.au

TABLE OF CONTENTS

I.	Important Safety Instructions	03
II.	Care Instructions	04
III.	Parts List	05
IV.	Assembly Instructions	07
٧.	Exercise Guide	11
VI.	Warranty	13

I. IMPORTANT SAFETY **INSTRUCTIONS**



🕦 WARNING: Read all instructions before using this product.

Please keep this manual with you at all times


- · It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained, and used properly. Please note: It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.
- Before starting any exercise program, you should consult your doctor to determine if you have any medical or physical conditions that could put your health and safety at risk, or prevent you from using the equipment properly. Your doctor's advice is essential if you are taking medication that affects your heart rate, blood pressure or cholesterol level.
- Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, and extreme shortness of breath, lightheadedness, dizziness, or feelings of nausea. If you do experience any of these symptoms, you should consult your doctor before continuing with your exercise program.
- Keep children and pets away from the equipment. This equipment is designed for adult use only.
- Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 2 meters of free space around it.
- · Before using the equipment, check that the nuts and bolts are securely tightened. If you hear any unusual noises coming from the equipment during use and assembly, stop immediately. Do not use the equipment until the problem has been rectified.
- · Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may get caught in the equipment or that may restrict or prevent movement.
- Care must be taken when lifting or moving the equipment so as not to injure your back.
- · Always keep this instruction manual and assembly tools at hand for reference.
- The equipment is not suitable for therapeutic use.

II. CARE INSTRUCTIONS

(!) IMPORTANT

- Where necessary, lubricate any moving joints with silicon spray after periods of usage.
- Be careful not to damage plastic or metal parts of the machine with heavy or sharp objects.
- The machine can be kept clean by wiping it down using dry cloth.
- · Regularly check all moving parts and make sure there are signs of wear and damage, if any the use of the device must be stopped immediately and contact our after-sales department.
- During inspection, it is necessary to make sure that all bolts and nuts are completely fixed. If any bolt or nut connection is loosened, please re-tighten.
- · Check weld for cracks.
- Failure to perform daily maintenance may result in personal injury or equipment damage.

III. PARTS LIST




No.	Name	Qty.	No.	Name	Qty.
1	Bottom Middle Connector	1	17	Foam	2
2	Left Base	1	18	Four-hole Connecting Plate	1
3	The Right Base	1	19	Back Cushion	1
4	Column Off the Shelves	1	20	Elbow Rest	2
5	Rear Support Frame	1	21	Carriage M10x90	4
6	Column on the Shelves	1	22	Carriage M10x70	4
7	Right Support Welding	1	23	Bolt M10x70	2
8	Left Support Welding	1	24	Bolt M10x16	10
9	Vertical Handle Welding	2	25	Bolt M10x120	1
10	Upper Lead Bending Frame	1	26	Bolt M8x65	6
11	Lead Ladder Frame	1	27	Bolt M8x10	4
12	70-Side 110 Connecting Board	1	28	Bolt M10x90	4
13	70-Side 150 Connecting Board	1	29	Ø10 Flat Gasket	32
14	Flat Connection Piece	2	30	M10 Nuts	15
15	Bubble Cotton Tube	1	31	Ø8 Flat Gasket	10
16	Four-hole Tile Plate	1			

IV. ASSEMBLY INSTRUCTIONS


NOTE:

- 1. The gasket needs to be placed at both ends of the bolts (against the bolt head and nut), as shown in images.
- 2. Do not fully tighten all bolts until the end. During assembly tighten all bolts and nuts by hand first then tighten with wrench at the end.
- 3. Some spare parts have been pre-assembled in the factory.
- 4. It is recommended to have assistance during assembly (e.g., 2 person).




STEP 1

- 1. Install (#3) into (#2) as shown and attach them together on both sides of (#1) with:
 - 2x (#14)
 - 4x bolts (#21)
 - 4x flat spacer (#29)
 - 4x nut (#30)
- 2. Pre-install (#13) and 2x bolts (#22) under (#1) as shown.
- 3. Preload (#12) and 2x bolts (#22) under (#2) and (#3) as shown.




STEP 2

- 1. Install (#4) onto (#1) and tighten with 2x flat spacers (#29) and 2x nut (#30).
- 2. Install (#5) onto (#2) and (#3) first and tighten it with 2x flat spacers (#29) and nut 2x (#30).
- 3. Insert (#6) into (#4) and connect it to (#5) using:
 - 1x (#16)
 - 2x bolts (#23)
 - 4x bolts (#24)
 - 6x flat pads (#29)
 - 4x nuts (#30)
- 4. Insert (#15) rod into (#4) and place (#17) onto (#15) on each end as shown.



STEP 3

- 1. Attach together (#7), (#8) and (#18) using:
 - 4x flat spacers (#29)
 - 4x bolts (#27) as shown.
- 2. Put the pre-installed parts in step 1 onto (#6) as shown and tighten them with 1x bolts (#25), 2x flat spacer (#29), and 1x nuts (#30).
- 3. Insert (#9) into (#7) and (#8) as shown and secure them with 2x bolts (#24) and 2x flat spacers (#29).
- 4. Place (#20) on (#7) and (#8) as shown and secure them with 4x bolts (#26) and 4x flat spacers (#31).
- 5. Place (#19) onto (#6) and secure with 2x bolts (#26) and 2x flat spacers (#31) as shown.



STEP 4

- 1. Attach (#10) and (#11) with 4x bolts (#28), 8x flat gasket (#29), and 4x nuts (#30) as pictured.
- 2. Place the pre-loaded pieces into (#6) as shown and tighten with 4x bolts (#24) and 4x flat spacer (#29).

Tighten up all the bolts and nuts with the wrench.

V. EXERCISE GUIDE

(!) PLEASE NOTE:


Before beginning any exercise program, consult your physician. This is important for individuals over the age of 45 or with pre-existing health problems.

The pulse sensors are not medical devices. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as an exercise aid in determining heart rate trends in general.

Exercising is great way to control your weight, improve your fitness and reduce the effect of aging and stress. The key to a healthy lifestyle is to make exercise a regular and enjoyable part of your everyday life.

The condition of your heart and lungs and how efficient they are in delivering oxygen via your blood to your muscles is an important factor to your fitness. Your muscles use this oxygen to provide enough energy for daily activity. This is called aerobic activity. When you are fit, your heart will not have to work so hard. It will pump a lot fewer times per minute, reducing the strain on your heart.

So as you can see, the fitter you are, the healthier and greater you will feel.



WARM UP


Start each workout with 5 to 10 minutes of stretching and some light exercises. A proper warm-up increases your body temperature, heart rate and circulation in preparation for exercise. Ease into your exercise.

After warming up, increase the intensity to your desired exercise program. Be sure to maintain your intensity for maximum performance. Breathe regularly and deeply as you exercise.

COOL DOWN

Finish each workout with a light jog or walk for at least 1 minute. Then complete 5 to 10 minutes of stretching to cool down. This will increase the flexibility of your muscles and will help prevent postexercise problems.

WORKOUT GUIDELINES



This is how your pulse should behave during general fitness exercise. Remember to warm up and cool down for a few minutes.

VI. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au.

Please visit our website to view our full warranty terms and conditions: http://www.lifespanfitness.com.au/warranty-repairs

WARRANTY AND SUPPORT

Any claim against this warranty must be made through your original place of purchase. Proof of purchase is required before a warranty claim may be processed.

If you have purchased this product from the Official Lifespan Fitness website, please visit https://lifespanfitness.com.au/warranty-form

For support outside of warranty, if you wish to purchase replacement parts or request a repair or service, please visit https://lifespanfitness.com.au/warranty-form and fill in our Repair/Service Request Form or Parts Purchase Form.

Scan this QR code with your device to go to lifespanfitness.com.au/warranty-form



