


GBH-300 POWER TOWER OWNER'S MANUAL





Product may vary slightly from the item pictured due to model upgrades Read all instructions carefully before using this product. Retain this owner's manual for future reference.

NOTE: This manual should not be used to guide your purchasing decision. Your product, and the contents inside its carton, may vary from what is listed in this manual. This manual may also be subject to updates or changes. Updated manuals are available through our website at www.lsgfitness.com.au.

TABLE OF CONTENTS

1.	IMPORTANT SAFETY INSTRUCTIONS	3
2.	CARE INSTRUCTIONS	4
3.	PARTS LIST	4
4.	ASSEMBLY INSTRUCTIONS	5
5.	WARRANTY	10



1. IMPORTANT SAFETY INSTRUCTIONS

WARNING - Read all instructions before using this product.

Please keep this manual with you at all times

- a. It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained and used properly. Please note: It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.
- b. Before starting any exercise program you should consult your doctor to determine if you have any medical or physical conditions that could put your health and safety at risk, or prevent you from using the equipment properly. Your doctor's advice is essential if you are taking medication that affects your heart rate, blood pressure or cholesterol level.
- c. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, and extreme shortness of breath, lightheadedness, dizziness or feelings of nausea. If you do experience any of these symptoms, you should consult your doctor before continuing with your exercise program.
- d. Keep children and pets away from the equipment. This equipment is designed for adult use only.
- e. Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 2 meters of free space around it.
- f. Before using the equipment, check that the nuts and bolts are securely tightened. If you hear any unusual noises coming from the equipment during use and assembly, stop immediately. Do not use the equipment until the problem has been rectified.
- g. Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may get caught in the equipment or that may restrict or prevent movement.
- h. This equipment is designed for indoor and family use only
- i. Care must be taken when lifting or moving the equipment so as not to injure your back.
- j. Always keep this instruction manual and assembly tools at hand for reference.
- k. The equipment is not suitable for therapeutic use.



2. CARE INSTRUCTIONS

- Lubricate moving joints with grease after periods of usage
- Be careful not to damage plastic or metal parts of the machine with heavy or sharp objects
- The machine can be kept clean by wiping it down using dry cloth


3. PARTS LIST

NO.	Name	Model	Quantity
1	Tube		2
2	Vertical Tube		4
3	Connection Tube		2
4	Connection Tube		1
5	Pulling Up Bar		1
6	Pulling Up Bar		1
7	Dip Frame		1
8	Bar Rest		2
9	Bar Support		2
10	Plate Rest		4
11	Pin		1
12	Butterfly Clip		4
14	Washer	Ф10	52
15	Pan Bolts	M10x65mm	26
16	Nuts	M10	26




4. ASSEMBLY INSTRUCTIONS

STEP 1:





STEP 2:




1. Attach the Connection Tube (#3) to the Vertical Tube (#2).

Secure it with:

- 4 Pan Bolts M10x65mm (#15)
- 8 Washers Φ10 (#14)
- 2. Install the other side the same way.

STEP 3:




1. Follow the chart, attach the Connection Tube (#4) to the Tubes (#2).

Secure it with:


- 8 Washers Φ10 (#14)
- 4 Pan Bolts M10x65mm (#15)
- 4 Nuts M10 (#16)

STEP 4:




- 1. Attach the Pulling Bar (#5) and Pulling Bar (#6) to the Connection Tube (#3). Secure it with:
 - 8 Pan Bolts M10x65mm (#15)
 - 16 Washers Φ10 (#14)
 - 8 Nuts M10 (#16)

STEP 5:



1. Plug the Dip Frame (#7) into the Vertical Tube (#2), locked with Pin (#11).

STEP 6:



- 1. Plug the 2xBar Rest (#8) into the Vertical Frame.
- 2. Plug the 2xBar Support (#9) into the Vertical Frame.
- 3. Plug the 4xPlate Rest (#10) into the Vertical Frame with Butterfly Clip (#12).

5. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au.

Please visit our website to view our full warranty terms and conditions: https://www.lsgfitness.com.au/pages/warranty

Warranty and Support:

Please email us at support@lsgfitness.com.au for all warranty or support issues.

For all warranty or support related enquiries an email must be sent before contacting us via any other means.

