


SSN100 All-In-One Single Station Pulley Machine

USER MANUAL



Product may vary slightly from the item pictured due to model upgrades.



Read all instructions carefully before using this product. Retain this owner's manual for future reference.

NOTE:

This manual may be subject to updates or changes. Up to date manuals are available through our website at www.lsgfitness.com.au

TABLE OF CONTENTS

I.	Important Safety Instructions	03
II.	Care Instructions	04
III.	Exploded Diagram	05
IV.	Parts List	06
V.	Assembly Instructions	07
VI.	Workout Guide	16
VII.	Exercise Guide	17
VII.	Warranty	19

I. IMPORTANT SAFETY **INSTRUCTIONS**

/i\ WARNING: Read all instructions before using this machine.

- Install the product on a flat level surface.
- · Place your unit on a solid, level surface when in use.
- Never allow children on or near the machine.
- Keep hands away from all moving parts.
- · Never drop or insert any object into any openings.
- Care must be taken when lifting or moving the equipment so as not to injure your back. Always use proper lifting techniques and/or seek assistance if necessary.
- · Keep children and pets away from the machine at all times. DO NOT leave children unattended in the same room with the machine.
- Only 1 person at a time should use the machine.
- · If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. CONSULT A PHYSICIAN IMMEDIATELY
- Do not use the machine near water or outdoors.
- Keep hands away from all moving parts.
- · Always wear appropriate workout clothing when exercising. DO NOT wear robes or other clothing that could become caught in the machine. Running or aerobic shoes are also required when using the machine.
- Use the machine only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer.
- · Do not place any sharp objects around the machine.
- Disabled person should not use the machine without a qualified person or physician in attendance.
- Never operate the machine if the machine is not functioning properly.
- A spotter is recommended during exercise.


II. CARE INSTRUCTIONS

- Lubricate moving joints with silicon spray after periods of usage.
- Be careful not to damage plastic or metal parts of the machine with heavy or sharp objects.
- The machine can be kept clean by wiping it down using dry cloth.
- Check and adjust the tension of wire rope on a regular basis.
- Regularly check all moving parts and make sure there are signs of wear and damage, if any the use of the device must be stopped immediately and contact our after-sales department.
- During inspection, it is necessary to make sure that all bolts and nuts are completely fixed. If any bolt or nut connection is loosened, please re-tighten.
- · Check weld for cracks.
- Failure to perform daily maintenance may result in personal injury or equipment damage.



Caution: Please always check your chain links parts are fully tightened or clipped in properly before use as this may cause injury if the links are not screwed all the way or clipped properly.

III. EXPLODED DIAGRAM




IV. PARTS LIST


Some items on this list may come pre-installed on your equipment. If you feel like you're missing anything, please double check your equipment.

1 Base Frame	Part No.	Description	Qty.	Part No.	Description	Qty.
3 Rear Stabilizer 1 40 MI2 Nylon Nut 6 4 Seat Support Tube 1 41 Fixed Pin for Weight Stack 1 5 Upright Support Tube 1 42 End Cap 6 6 Leg Curl Tube 1 43 φ60 Round Cap 2 7 Guiding Tube 2 44 φ60 Flat Cap 2 8 Bridge Tube 1 45 φ50.8 Flat Cap 8 9 Pull unit 1 46 φ25.4 Flat Cap 6 10 Butterfly Arm - Left 1 47 Pin 1 10R Butterfly Arm - Right 1 48 Rubber Ring 2 11 Handlebar 2 49 Pulley 11 12 Lat Bar 1 50 Cap for Small Pulley 11 13 Lower Pull Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt MI2X108 mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 1 55 Foam for Handlebar 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley 8 7 11 58 Round Cap for Seat/Backrest 2 51 Plastic Bushing 4 18 Two Way Bracket for Pulley 1 55 Foam for Handlebar 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 Hex Head Bolt MI2 X SommL 2 60 Seat 1 23 Hex Head Bolt MI0 x 60mmL 2 60 Seat 1 24 Hex Head Bolt MI0 x 60mmL 3 62 Hook 5 25 Hex Head Bolt MI0 x 50mmL 4 64 Weight Stack 8 Lbs 1 27 Hex Head Bolt MI0 x 75mmL 4 64 Weight Stack 8 Lbs 1 28 Hex Head Bolt MI0 x 75mmL 4 64 Weight Stack 8 Lbs 1 29 Hex Head Bolt MI0 x 75mmL 1 65 Cable for Lat Bar 1 30 Hex Head Bolt MI0 x 75mmL 1 65 Cable for Lat Bar 1 31 Powder Metal Ring el? 4 68 Cushion Support tube 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XIDB.3 10 71 Knob 1 34 Curve Washer OD22XIDB.3 10 71 Knob 1 35 Flat Washer OD22XIDB.3 20 74 Spring 1 36 Flat Washer OD22XIDB.3 20 74 Spring 1	1	Base Frame	1	38	M8 Nylon Nut	2
4 Seat Support Tube 1 41 Fixed Pin for Weight Stack 1 5 Upright Support Tube 1 42 End Cap 6 6 1 Leg Curl Tube 1 1 42 End Cap 2 2 44 960 Round Cap 2 2 44 960 Flat Cap 8 8 Bridge Tube 1 1 45 φSO.8 Flat Cap 8 8 Pridge Tube 1 1 45 φSO.8 Flat Cap 8 9 Pull unit 1 1 46 φ25.4 Flat Cap 6 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2	Seat post	1	39	M10 Nylon Nut	26
5 Upright Support Tube 1 42 End Cap 6 6 Leg Curl Tube 1 43 q60 Round Cap 2 7 Guiding Tube 2 44 q60 Flat Cap 8 8 Bridge Tube 1 45 q50.8 Flat Cap 8 9 Pull unit 1 46 q25.4 Flat Cap 6 10L Butterfly Arm - Left 1 47 Pin 1 10R Butterfly Arm - Right 1 48 Rubber Ring 2 11 Handlebar 2 49 Pulley 11 12 Lat Bear 1 49A Pulley A 1 13 Lower Pull Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 4 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Sackrest 2 52 Rubber S	3	Rear Stabilizer	1	40	M12 Nylon Nut	6
6 Leg Curl Tube 1 43 φ60 Round Cap 2 7 Guiding Tube 2 44 φ60 Flat Cap 2 8 Bridge Tube 1 45 φ50.8 Flat Cap 8 9 Pull unit 1 46 φ25.4 Flat Cap 6 10L Butterfly Arm - Left 1 47 Pin 1 10R Butterfly Arm - Left 1 47 Pin 1 10R Butterfly Arm - Right 1 48 Rubber Ring 2 11 Handlebar 2 49 Pulley 11 12 Lat Bar 1 50 Cap for Small Pulley 2 12 Lat Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg Curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt MIXXIOSmml 2 53 Foam	4	Seat Support Tube	11	41	Fixed Pin for Weight Stack	1
7 Guiding Tube 2 44 φ60 Flat Cap 2 8 Bridge Tube 1 45 φ50.8 Flat Cap 8 9 Pull unit 1 46 φ25.4 Flat Cap 6 10L Butterfly Arm - Left 1 47 Pin 1 10R Butterfly Arm - Right 1 48 Rubber Ring 2 11 Handlebar 2 49 Pulley 11 12 Lat Bar 1 49A Pulley A 1 13 Lower Pull Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt M12X108 mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1	5	Upright Support Tube	1	42	End Cap	6
8 Bridge Tube 1 45 φ50.8 Flat Cap 6 9 Pull unit 1 46 φ25.4 Flat Cap 6 10L Butterfly Arm - Left 1 47 Pin 1 10R Butterfly Arm - Right 1 48 Rubber Ring 2 11 Handlebar 2 49 Pulley 11 12 Lat Bar 1 49A Pulley A 1 13 Lower Pull Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Both MI2X108 mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1 55 Foam for Hundlebar 2 19 Select Bar 1	6	Leg Curl Tube	1	43	φ60 Round Cap	2
9 Pull unit 1 46 φ25.4 Flat Cap 6 10L Butterfly Arm - Left 1 47 Pin 1 10R Butterfly Arm - Right 1 48 Rubber Ring 2 11 Handlebar 2 49 Pulley 11 12 Lat Bar 1 49A Pulley A 1 13 Lower Pull Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt MI2XIOS mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Butderfly Arm 2 18 Two Way Bracket for Pulley 1 55 Foam for Butterfly Arm 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket <th< th=""><th>7</th><th>Guiding Tube</th><th>2</th><th>44</th><th>φ60 Flat Cap</th><th>2</th></th<>	7	Guiding Tube	2	44	φ60 Flat Cap	2
10L Butterfly Arm - Left 1 47 Pin 1 10R Butterfly Arm - Right 1 48 Rubber Ring 2 11 Handlebar 2 49 Pulley 11 12 Lat Bar 1 49A Pulley A 1 13 Lower Pull Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt M12X108 mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1 55 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1 55 Foam for Leg Curl 4 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket	8	Bridge Tube	1	45	φ50.8 Flat Cap	8
10R Butterfly Arm - Right 1 48 Rubber Ring 2 11 Handlebar 2 49 Pulley 11 12 Lat Bar 1 49A Pulley A 1 13 Lower Pull Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt MI2X108 mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Butterfly Arm 2 18 Two Way Bracket for Pulley 1 55 Foam for Handlebar 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle	9	Pull unit	1	46	φ25.4 Flat Cap	6
11 Handlebar 2 49 Pulley 11 12 Lat Bar 1 49A Pulley A 1 13 Lower Pull Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt MI2XIO8 mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1 55 Foam for Handlebar 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 <	10L	Butterfly Arm - Left	1	47	Pin	1
12 Lat Bar 1 49A Pulley A 1 13 Lower Pull Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt M12XIOS mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1 55 Foam for Leg Curl 4 20 Pulley Bracket 2 54 Foam for Leg Curl 4 20 Pulley Bracket 2 55 Foam for Leg Curl 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 20 Pulley Bracket 2 57 Bushing for Weight Stack 1	10R	Butterfly Arm - Right	1	48	Rubber Ring	2
13 Lower Pull Bar 1 50 Cap for Small Pulley 2 14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt M12X108 mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1 55 Foam for Handlebar 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 Hex Head Bolt MID x 20mmL 10 59 Beck cushion 1	11	Handlebar	2	49	Pulley	11
14 Foam Tube for Leg curl 2 51 Plastic Bushing 4 15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt MI2X108 mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1 55 Foam for Handlebar 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 Hex Head Bolt MB x 20mmL 10 59 Beck cushion 1 23 Hex Head Bolt MI0 x 40mmL 2 60 Seat 1 </th <th>12</th> <th>Lat Bar</th> <th>11</th> <th>49A</th> <th>Pulley A</th> <th>1</th>	12	Lat Bar	11	49A	Pulley A	1
15 Bracket for Seat/Backrest 2 52 Rubber Stopper 1 16 Hex Head Bolt MI2X108 mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1 55 Foam for Handlebar 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 Hex Head Bolt MS x 20mmL 10 59 Beck cushion 1 22 Hex Head Bolt MI0 x 20mmL 2 60 Seat 1 24 Hex Head Bolt MS x 15mmL 18 61 Chain 6 Links 2 25 Hex Head Bolt MI0 x 40mmL 9 62 Hook 5	13	Lower Pull Bar	1	50	Cap for Small Pulley	2
16 Hex Head Bolt M12X108 mml 2 53 Foam for Butterfly Arm 2 17 Bracket for Pulley 2 54 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1 55 Foam for Handlebar 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 Hex Head Bolt M10 x 20mmL 10 59 Beck cushion 1 22 Hex Head Bolt M10 x 60mmL 2 60 Seat 1 24 Hex Head Bolt M10 x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9	14	Foam Tube for Leg curl	2	51	Plastic Bushing	4
17 Bracket for Pulley 2 54 Foam for Leg Curl 4 18 Two Way Bracket for Pulley 1 55 Foam for Handlebar 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 Hex Head Bolt MIO x 60mmL 2 60 Seat 1 24 Hex Head Bolt MIO x 60mmL 2 60 Seat 1 25 Hex Head Bolt MIO x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt MIO x 75mmL 4 64 Weight Stack 10 Lbs 9 <th>15</th> <th>Bracket for Seat/Backrest</th> <th>2</th> <th>52</th> <th>Rubber Stopper</th> <th>1</th>	15	Bracket for Seat/Backrest	2	52	Rubber Stopper	1
18 Two Way Bracket for Pulley 1 55 Foam for Handlebar 2 19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 Hex Head Bolt M8 x 20mmL 10 59 Beck cushion 1 23 Hex Head Bolt M10 x 60mmL 2 60 Seat 1 24 Hex Head Bolt M8 x 15mmL 18 61 Chain 6 Links 2 25 Hex Head Bolt M10 x 40mmL 9 62 Hook 5 26 Hex Head Bolt M10 x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9 28 Hex Head Bolt M10 x 75mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M10 x 80mmL 7 67 Cable for Butterfly Arm 1	16	Hex Head Bolt M12X108 mml	2	53	Foam for Butterfly Arm	2
19 Select Bar 1 56 Hand Grip 4 20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 Hex Head Bolt M8 x 20mmL 10 59 Beck cushion 1 23 Hex Head Bolt M10 x 60mmL 2 60 Seat 1 24 Hex Head Bolt M10 x 40mmL 18 61 Chain 6 Links 2 25 Hex Head Bolt M10 x 40mmL 9 62 Hook 5 26 Hex Head Bolt M10 x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9 28 Hex Head Bolt M10 x 70mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M10 x 80mmL 7 67 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Butterfly Arm 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID10.3 8 75 Cloth Cover for Left/Right 2	17	Bracket for Pulley	2	54	Foam for Leg Curl	4
20 Pulley Bracket 2 57 Bushing for Weight Stack 1 21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 Hex Head Bolt M8 x 20mmL 10 59 Beck cushion 1 23 Hex Head Bolt M10 x 60mmL 2 60 Seat 1 24 Hex Head Bolt M8 x 15mmL 18 61 Chain 6 Links 2 25 Hex Head Bolt M10 x 40mmL 9 62 Hook 5 26 Hex Head Bolt M10 x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9 28 Hex Head Bolt M10 x 70mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M10 x 75mmL 1 66 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69	18	Two Way Bracket for Pulley	11	55	Foam for Handlebar	2
21 Axle for Pull Unit 1 58 Round Cap for Select Bar 1 22 Hex Head Bolt M8 x 20mmL 10 59 Beck cushion 1 23 Hex Head Bolt M10 x 60mmL 2 60 Seat 1 24 Hex Head Bolt M8 x 15mmL 18 61 Chain 6 Links 2 25 Hex Head Bolt M10 x 40mmL 9 62 Hook 5 26 Hex Head Bolt M10 x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9 28 Hex Head Bolt M10 x 70mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M12x 75mmL 1 66 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stoppe	19	Select Bar	1	56	Hand Grip	4
22 Hex Head Bolt M8 x 20mmL 10 59 Beck cushion 1 23 Hex Head Bolt M10 x 60mmL 2 60 Seat 1 24 Hex Head Bolt M8 x 15mmL 18 61 Chain 6 Links 2 25 Hex Head Bolt M10 x 40mmL 9 62 Hook 5 26 Hex Head Bolt M10 x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9 28 Hex Head Bolt M10 x 70mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M12x 75mmL 1 66 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD23XID10.3 6 72 Elbow Cushion <th>20</th> <th>Pulley Bracket</th> <th>2</th> <th>57</th> <th>Bushing for Weight Stack</th> <th>1</th>	20	Pulley Bracket	2	57	Bushing for Weight Stack	1
23 Hex Head Bolt M10 x 60mmL 2 60 Seat 1 24 Hex Head Bolt M8 x 15mmL 18 61 Chain 6 Links 2 25 Hex Head Bolt M10 x 40mmL 9 62 Hook 5 26 Hex Head Bolt M10 x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9 28 Hex Head Bolt M10 x 70mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M10 x 80mmL 1 66 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD23XID3.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion	21	Axle for Pull Unit	1	58	Round Cap for Select Bar	1
24 Hex Head Bolt M8 x 15mmL 18 61 Chain 6 Links 2 25 Hex Head Bolt M10 x 40mmL 9 62 Hook 5 26 Hex Head Bolt M10 x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9 28 Hex Head Bolt M10 x 70mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M12x 75mmL 1 66 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35A Flat Washer OD23XID10.3 20 73 Bracket for Cloth	22	Hex Head Bolt M8 x 20mmL	10	59	Beck cushion	1
25 Hex Head Bolt M10 x 40mmL 9 62 Hook 5 26 Hex Head Bolt M10 x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9 28 Hex Head Bolt M10 x 70mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M12x 75mmL 1 66 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right<	23	Hex Head Bolt M10 x 60mmL	2	60	Seat	1
26 Hex Head Bolt M10 x 45mmL 1 63 Weight Stack 8 Lbs 1 27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9 28 Hex Head Bolt M10 x 70mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M12x 75mmL 1 66 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35A Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Co	24	Hex Head Bolt M8 x 15mmL	18	61	Chain 6 Links	2
27 Hex Head Bolt M10 x 75mmL 4 64 Weight Stack 10 Lbs 9 28 Hex Head Bolt M10 x 70mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M12x 75mmL 1 66 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	25	Hex Head Bolt M10 x 40mmL	9	62	Hook	5
28 Hex Head Bolt M10 x 70mmL 1 65 Cable for Lat Bar 1 29 Hex Head Bolt M12x 75mmL 1 66 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	26	Hex Head Bolt M10 x 45mmL	1	63	Weight Stack 8 Lbs	1
29 Hex Head Bolt M12x 75mmL 1 66 Cable for Butterfly Arm 1 30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	27	Hex Head Bolt M10 x 75mmL	4	64	Weight Stack 10 Lbs	9
30 Hex Head Bolt M10 x 80mmL 7 67 Cable for Lower Pull Bar 1 31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	28	Hex Head Bolt M10 x 70mmL	1	65	Cable for Lat Bar	1
31 Powder Metal Ring φ12 4 68 Cushion Support tube 1 31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	29	Hex Head Bolt M12x 75mmL	1	66	Cable for Butterfly Arm	1
31A Powder Metal Ring φ16 2 69 Bushing 1 32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	30	Hex Head Bolt M10 x 80mmL	7	67	Cable for Lower Pull Bar	1
32 Select Pin 1 70 Rubber Stopper 1 33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	31	Powder Metal Ring φ12	4	68	Cushion Support tube	1
33 Curve Washer OD22XID8.3 10 71 Knob 1 34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	31A	Powder Metal Ring φ16	2	69	Bushing	1
34 Curve Washer OD23XID10.3 6 72 Elbow Cushion 1 35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	32	Select Pin	1	70	Rubber Stopper	1
35 Flat Washer OD23XID10.3 20 73 Bracket for Cloth Cover 4 35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	33	Curve Washer OD22XID8.3	10	71	Knob	1
35A Flat Washer OD23XID8.3 20 74 Spring 1 36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	34	Curve Washer OD23XID10.3	6	72	Elbow Cushion	1
36 Flat Washer OD24XID12.3 8 75 Cloth Cover for Left/Right 2	35	Flat Washer OD23XID10.3	20	73	Bracket for Cloth Cover	4
Je Sieth Governer Love, Might	35A	Flat Washer OD23XID8.3	20	74	Spring	1
37 Flat Washer OD40XID12.5 2 76 Plum-nut 1	36	Flat Washer OD24XID12.3	8	75	Cloth Cover for Left/Right	2
	37	Flat Washer OD40XID12.5	2	76	Plum-nut	1


V. ASSEMBLY INSTRUCTIONS




- 1. Attach the Rear Stabilizer (03) to the Seat Support Tabe (04) and tighten by X2 Hex Head Bolt (27), X4 Curve Washer (34) and X2 Nylon Nuts (39).
- 2. Attach the Upright support tube (02) to the Seat Support Tabe (04) and tighten by X2 Hex Head Bolt (30), X4 Flat Washer (35) and X2 Nylon Nuts (39).
- 3. Attach the Base Frame (01) to Upright support tube (02) and tighten by X2 hex Head Bolt (27), X4 Flat Washer (34) and X2 Nylon Nuts (39).
- 4. Attach the Main support tube (05) to the Seat Support Tube (04) and tighten by X2 hex Head Bolt (30), X4 Flat Washer (35) and X2 Nylon Nuts (39).




- 1. Attached the Bracket for Cloth Cover L (73) to he Rear stabilizer (03) and tighten by X2 Hex Head Bolt (24), X2 Washer (35A).
- 2. Do the same procedure for the Bracket for Cloth Cover R (73) to the right side of Rear stabilizer (03) by the same parts.
- 3. Slide both Guiding Tube (07) through Rubber Ring (48) into the 2 holes on the Rear Stabilizer (3), tighten from the bottom side by X2 Curve Washer (33) and X2 Hex Head Bolt (22).
- 4. Place the Weight Stack (64) into the Guiding tube (07). (Be careful loading the weights and seek assistance where needed.)
- 5. Place the Bushing for Weight Stack (57) onto the Select Bar (19) and fixed by the Fixed Pin (41). Then place the Weight Stack (63) upper the Select Bar (19) and place the Flat Washer (37) upper the Weight Stack (63).
- 6. Insert the Select Pin (32) through the Weight Stack (64) into the hole of Select Bar (19).




- 1. Place the Guiding Tube (07) into the Bridge Tube (8) and tighten by X2 Flat Washer (33) and X2 Hex Head Bolt (22).
- 2. Attach the Bridge Tube (8) to the Upright Support Tube (05) and tighten by X2 Hex Head Bolt (30), X4 Flat Washer (35) and X2 Nylon Nuts (39).



- 1. Attach the Backrest (15) to the Upright support tube (05), tighten by X2 Curve Washer (34) and X2 Nylon Nuts (39) through the thread holes on the Upright support tube (05).
- 2. Attach the Backrest Cushion (59) onto the Upright Support Tube (05) by putting the screw on the Bracket for Backrest (15) into holes on Upright Support Tube (05), tighten by X4 hex Flat washer (35A), X4 Hex held bolt (24).
- 3. Attach the Seat (60) onto the Seat Support Tube (04) by putting the screw on the Bracket for Seat into holes, tighten by X4 hex Flat washer (35A), X4 Hex held bolt (24).
- 4. Attach the Elbow Cushion (72) onto the Elbow Cushion Support Tube (68) tighten by X4 Washer (35A), X4 Hex held bolt (24).
- 5. Attach the Elbow Cushion Support Tube(68) into the Seat Support Tube(04), then roll with the Knob(71).
- 6. Screw-in the Small Rubber Stopper (52) into the front side of Seat Support Tube (04).
- 7. Attach the Leg Curve Tube (06) to the front side of Seat Support Tube (04), tighten by X1 Hex Head Bolt (29), X2 Flat Washer (36) and X1 Nylon Nut (40).
- 8. Attach the Foam Tube for Leg Curl (14) into the holes on Leg Curl Tube (06) and front/upper bracket of Seat Support Tube (04).
- 9. Attach the Foam for Leg Curl Tube (54) onto the 2 sides of each Foam Tube for Leg Curl (14).




- 1. Attach the Pull Unit (09) to the Bridge Tube (08), insert the Axle for Pull Unit (21) through X2 Powder Metal Ring (31A), X2 Flat washer (36), X2 Nylon Nuts (40).
- 2. Attach the Butterfly Arm R (10R) to the right side of Pull Unit (09) through X2 Powder Metal Ring (31) and X2 Flat Washer (36) and tighten by X Nylon Nut (40).
- 3. Do the same procedure for the Butterfly Arm L (10L) to the Pull Unit (9) by same parts.
- 4. Insert the Rubber Stopper 70 to the bracket on the Upright Support tube (05). Then adjust the Pull Unit (09) to match the hole in the bracket.
- 5. Put the Foam for Butterfly Arm (53) onto the R/L Butterfly Arm (10R & 10L) and adjust to certain position.
- 6. Attach the Handlebar (11) onto the ButterflyArm R (10R), tighten by X3 Curve Washer (33) and X3 Hex Head Bolt (22). Do the same procedure of Butterfly Arm L (10L) with the other Handlebar (11).
- 7. Attach the Pulley Bracket (20) onto the 2 sides of Upright Support Tube (05), tighten by X2 Hex Head Bolt (23), X4 Flat Washer (35) and X2 Nylon nuts (39) for 2 sides.




1. Attach the Cable for Lat Bar (65) to the opening bracket at the front of the Bridge Tube (8). Note: The ball stopper of the Cable (65) should be underneath the Bridge Tube (8). Attach the Cable (65) onto the Small Pulley (49A) and put the Cap for Small Pulley (50) to the two side of Small Pulley (49A).

Note: The Cable (65) has to come out of the Cap (50) from the opening sides. Tighten to the bracket by X1 Hex Head Bolt (26) and X1 Nylon Nut (39).


- 2. Draw the Cable (65) towards the back side of the machine through the upper opening of Upright Support Tube (05) and around Pulley (49), then attach the Pulley (49) onto bracket A as drawing, tighten by X1 Hex Head Bolt (25) and X1 Nylon Nut (39).
- 3. Draw the Cable (65) downwards and aroundPulley (49). Attach the Pulley (49) with the Bracket for Pulley (17) on two sides then tighten by X1 Hex Head Bolt (25) and X1 Nylon Nut (39).
- 4. Draw the Cable (65) upwards and around Pulley (49). Attach the Pulley (49) to bracket B and tighten by X1 Hex Head Bolt (25) and X1 Nylon Nut (39).
- 5. Draw the Cable (65) downwards between the two Guiding Tube (07) and fully thread the bolt on the end of the Cable (65) into the top opening on the Select Bar (19).
- 6. Attach the Lat Bar (12) to the front end of the Cable (65), connect by X1 Hook (62).



- 1. Attach one end of the Cable for Butterfly Arm (66) to the hook on the Right Butterfly Arm (10R), tighten by X1 Hex Head Bolt (24), X1 Flat Washer (35A) and X1 Nylon Nut (38).
- 2. Draw the Cable (66) around the Pulley (49) then attach the Pulley (49) to the Pulley Bracket (20) on right side of the Upright Support Tube (05), tighten by X1 Hex Head Bolt (25) and X1 Nylon Nut (39).
- 3. Draw the Cable (66) downward and around the Pulley (49), attach the Pulley (49) to the upper part of Two Way Bracket for Pulley (18) and tighten by X1 Hex Head Bolt (25) and X1 Nylon Nut (39).
- 4. Draw the Cable (66) upward and around Pulley (49). Attach Pulley (49) to the Pulley Bracket (20) on the left side of the upright Support Tube (05), tighten by X1 Hex Head Bolt (25) and X1 Nylon Nut (39).
- 5. Attach the other end of Cable (66) to the hook on the Left Butterfly Arm (10L), tighten by X1 Hex Head Bolt (24), X1 Flat Washer (35A) and X1 Nylon Nut (38).




- 1. Attach the end with stopper ball of Cable for Lower Pull Bar (67) to the open bracket Leg Curl Tube (6), around the under side of Pulley (49). Then draw the Cable (67) through the opening space on the lower part of Seat post (02), around the Pulley (49) from under side, then draw the Cable (67) upward and around the upper side of Pulley (49). Attach the Pulley (49) to the under side of Two Way Bracket for Pulley (18), tighten by X1 Hex Head Bolt (25) and X1 Nylon Nut (39).
- 2. Draw the Cable (67) downward and around the under side of Pulley (49). Attach the Pulley (49) to bracket D on the Seat post tube (4) and tighten by X1 Hex Head Bolt (25) and X1 Nylon Nut(39).
- 3. Draw the Cable (67) upward and around the upper side of Pulley (49). Attach the Pulley (49) to the under side of Bracket for Pulley (17) set and tighten by X1 Hex Head Bolt (25) and X1 Nylon Nut (39).
- 4. Draw the Cable (67) downward and connect with bracket E on Rear stabilizer (3) by Chain 6 Links (61) and X2 Hook (62). Note: Adjust the Cable (67) to be tighten enough and lock on certain position of Chain (61) by Hook (62). certain position of Chain (61) by Hook (62).
- 5. Attach the Lower Pull Bar (13) to the front end of Cable (67), connecting by Chain 6 Links (61) and X2 Hook (62).



- 1. Attached the Bracket for Cloth Cover L (73) to the Bridge Tube (08) and tighten by X2 Hex HeadBolt (24), X2 Washer (35 A).
- 2. Do the same procedure for the Bracket for Cloth Cover R (73) to the right side of Bridge Tube (08) by the same parts.
- 3. Attach the Left Cloth Cover (75) to the Bracket for Cloth Cover L (73).
- 4. Do the same procedure for Right Cloth Cover (75) to the right side by the same parts.

VI. WORKOUT GUIDE

BICEPS & TRICEPS

















CHEST & SHOULDERS







CORE & BACK










LEGS



VII. EXERCISE GUIDE

!) PLEASE NOTE:


Before beginning any exercise program, consult your physician. This is important especially if you are over the age of 45 or individuals with pre-existing health problems.

The pulse sensors are not medical devices. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as an exercise aid in determining heart rate trends in general.

Exercising is great way to control your weight, improving your fitness and reduce the effect of aging and stress. The key to success is to make exercise a regular and enjoyable part of your everyday life.

The condition of your heart and lungs and how efficient they are in delivering oxygen via your blood to your muscles is an important factor to your fitness. Your muscles use this oxygen to provide enough energy for daily activity. This is called aerobic activity. When you are fit, your heart will not have to work so hard. It will pump a lot fewer times per minute, reducing the wear and tear of your heart.

So as you can see, the fitter you are, the healthier and greater you will feel.



WARM UP


Start each workout with 5 to 10 minutes of stretching and some light exercises. A proper warm-up increases your body temperature, heart rate and circulation in preparation for exercise. Ease into your exercise.

After warming up, increase the intensity to your desired exercise program. Be sure to maintain your intensity for maximum performance. Breathe regularly and deeply as you exercise.

COOL DOWN

Finish each workout with a light jog or walk for at least 1 minute. Then complete 5 to 10 minutes of stretching to cool down. This will increase the flexibility of your muscles and will help prevent postexercise problems.

WORKOUT GUIDELINES



! This is how your pulse should behave during general fitness exercise. Remember to warm up and cool down for a few minutes.

18 | EXERCISE GUIDE WARRANTY |

VII. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au.

Please visit our website to view our full warranty terms and conditions: https://www.lsgfitness.com.au/pages/warranty

WARRANTY AND SUPPORT

Please email us at support@lsgfitness.com.au for all warranty or support issues.

For all warranty or support related enquiries, please lodge a support ticket first by sending us an email.

