

Age Range: 3- 12 years

To be retained for future reference.



ASSEMBLY INSTRUCTIONS

IMPORTANT:

- Before each use, please check product carefully for damage.
- Do not allow use of rope ladder until it has been installed properly by an adult, according to these instructions.
- By no means use the rope ladder as an infant seat.
- Only one child in the rope ladder at a time.
- Adult supervision required to make sure that children play safely.
- Make sure your child is dressed suitably to stop possible hazards happening While Using the rope ladder. Your child should not wear loose clothing such as ponchos or Scarves. Apparel should include well fitting shoes.
- Evaluate the following safety tips with your child before use:
- do not walk too close to, in front of, or behind the rope ladder while it is in use.
- Do not get out of the rope ladder while it is in motion.
- Do not push the rope ladder when it is not occupied.
- Do not twist or spin the rope ladder.
- Do not stand in the rope ladder.

WARNING! For outdoor domestic use only

WARNING! Adult supervision at all times.

WARNING! This item is to be assembled and disassembled by an adult.

WARNING! Head or other injuries may result when falling onto hard surfaces.

WARNING! Never place rope ladder over concrete, asphalt, wood or other hard surfaces.

WARNING! At all times use the restraint system.

WARNING! Never leave child unattended.

WARNING! Max. user weight 50 kgs.

WARNING! Not suitable for usage until fully assembled- small parts-choke hazard.





WARNING! To prevent falls, use restraint system at all times.


WARNING! Never leave child unattended.

WARNING! Not to be used by children under 36 months.

1-Location of apparatus.

Minimal space in mm to respect between apparatus and structure of portico

Space in millimetres between	 Free elements	 Semi-flexible elements	 Endowed with stiff suspension	 Neighbouring Structure of swings
Free balance elements	450	450	450	300
Semi-flexible elements	450	300	300	300
Endowed with stiff suspension	450	300	300	300



2- Fixation of apparatus on the hook

The location of the hook carbine must be perpendicular in the axis of the beam of the portico, so that the balance of apparatus is correctly made.

The toy must be placed on a level surface at least 2meter from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires.

The toy shall not be installed over concrete, asphalt or any other hard surface.

3-Control and Maintenance

Control regularly the state of the elements of suspension. Verify monthly the good tightening of all screws and nuts, and systems of fixation of apparatus, to prevent the falling risks replace all the damaged masks or missing nuts. Remove apparatus during the wintry period to avoid any premature degradation concerning the bad weather, from the slightest appearance of degradation of apparatus, and at least after 24 months of exposure outdoors, replace them by apparatus of the same conception. The change must be more frequent in zones with strong period of sunshine.

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au

Please visit our website to view our full warranty terms and conditions:

<http://www.lifespankids.com.au/Warranty-Policy-Kids>

Please email us at support@lifespankids.com.au for all warranty or support issues.

