

USER MANUAL

Spidey Web Swing 60cm



Find the Digital
Manual Online



WARNING: The disassembled product may contain small parts which pose a choking hazard to children under 3.

IMPORTANT:

The owner's manual contains safety, assembly, use and maintenance instructions. This product must be assembled by an adult who has read and understood these instructions. Keep the packaging away from children and dispose of all packaging before use.

For the installer and your children's safety, it is important to fully read and understand the instructions and safety hazards before commencing the assembly of the product.

ASSEMBLY INSTRUCTIONS

1. Stable garden swing with plaited seat and a stable metal ring.
2. Dimensions after assembly approx. Ø 100cm x (H) 180cm
3. Seat and fastening rope made from skin-friendly, weather proof PE material.
4. Stable and durable mesh seat (Ø7mm) with metal ring on the outer side.
5. Stable suspension ropes (Ø 10mm, L180cm) with metal rings for secured fastening.
6. Weight load max.: 150kg.

SAFETY INSTRUCTIONS:

1. Please preserve this manual and the packing carefully for later reference. If you give this product to a third party remember to hand over this manual as well.
2. This product is NOT meant for commercial use, but is ONLY intended for domestic use. To be used only under the supervision of adults. Never leave your child unsupervised on the swing, in order to avoid the risk of falling down.
3. Follow the assembly and maintenance instructions, in order to prevent your child from falling, tumbling down and to prevent the tearing of ropes.
4. We recommend that you set up the swing on an even surface and maintain a distance of at least 2 m from other structures or obstacles, e.g. fence, garage, house, projecting branches, clotheslines or electric cables.
6. Not suitable for children below 3 years of age. Risk of strangulation!
7. Children below 3 years of age are still unable to maintain their balance.
8. Since children have different development patterns, please check beforehand if your child is able to maintain his balance.


MAINTENANCE:

- Always pay attention to the following points if the swing was not in use for a longer period (Especially at the beginning of a new season!).
- Lubricate all metal parts. Check all the caps on screws and sharp edges and replace them, if required.
- Check the swing seats, chains, ropes and other accessories for any signs of wear. If required, replace these as per the manufacturer's instructions.
- Check the ropes and rings constantly for decay, wear and tear resistance. The best way to check this is to turn the ropes till their inside becomes visible! Check the knots regularly for tightness. Examine the wood regularly for decay and cracks.
- Also check if wood shavings are sticking out from the swing board. These should be abraded in order to avoid injuries. Do not expose the swing to the weather during longer periods of rain and in autumn / winter. Always replace defective parts with original spares.


! ATTENTION

- Check the quality / condition of the hooks, from which the swing is suspended, regularly. The screw-in hooks must be smooth in order to avoid friction and thereby material wear.
- Changes to the original toy (e.g. fixing an add-on part) must be made only as per the instructions of the manufacturer of the original toy.


HOW TO TIE THE ROPE:




1. Feed the rope to the spidey web from inside.




2. Loop the short end of rope over the spidey web ring and then behind the main rope. This creates the first crossover (1).



3. Cross it over (1) then loop it back behind the web ring. (2) Cross over is created from inside.




4. Holding the short end rope, cross it back to the front over (2) and insert into (1) rope.




5. Bring the ties together and pull both ends to tighten fully. Repeat for the other ropes. Check that all sides are even and adjust further where needed.

HOW TO TIE THE ROPE:


Shorten Ropes (lengthening the ropes is the same steps but in reverse)




1. Loosen the main rope to your desired amount for shortening the rope.




2. Follow the loosened rope on the other side and pull it through.



3. Follow the loosened rope (2) to the other side and pull it through.



4. Pull the final loosened rope (3) from the end of the rope.



5. Bring the ties together and pull both ends to tighten fully. Check that all sides are even and adjust further where needed.

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au.

Please visit our website to view our full warranty terms and conditions: www.lifespankids.com.au/Warranty-Policy-Kids