


CORTEX[®]

FT11 Plate Loaded Cable Fly Machine

USER MANUAL



Product may vary slightly from the item pictured due to model upgrades.



**Read all instructions carefully before using this product.
Retain this owner's manual for future reference.**

NOTE:

This manual may be subject to updates or changes. Up to date manuals are available through our website at www.lifespanfitness.com.au



TABLE OF CONTENTS

I. Important Safety Instructions	03
II. Care Instructions	04
III. Assembly Instructions	05
IV. Parts List	08
V. Exercise Guide	09
VI. Warranty	11

I. IMPORTANT SAFETY INSTRUCTIONS

 **WARNING: Read all instructions before using this machine.**

- Install the product on a flat level surface.
- Place your unit on a solid, level surface when in use.
- Never allow children on or near the machine.
- Keep hands away from all moving parts.
- Never drop or insert any object into any openings.
- Care must be taken when lifting or moving the equipment so as not to injure your back. Always use proper lifting techniques and/or seek assistance if necessary.
- Keep children and pets away from the machine at all times. **DO NOT** leave children unattended in the same room with the machine.
- Only 1 person at a time should use the machine.
- If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, **STOP** the workout at once. **CONSULT A PHYSICIAN IMMEDIATELY.**
- Do not use the machine near water or outdoors.
- Keep hands away from all moving parts.
- Always wear appropriate workout clothing when exercising. **DO NOT** wear robes or other clothing that could become caught in the machine. Running or aerobic shoes are also required when using the machine.
- Use the machine only for its intended use as described in this manual. **DO NOT** use attachments not recommended by the manufacturer.
- Do not place any sharp objects around the machine.
- Disabled person should not use the machine without a qualified person or physician in attendance.
- Never operate the machine if the machine is not functioning properly.
- A spotter is recommended during exercise.

II. CARE INSTRUCTIONS

- Lubricate moving joints with silicon spray after periods of usage.
- Be careful not to damage plastic or metal parts of the machine with heavy or sharp objects.
- The machine can be kept clean by wiping it down using dry cloth.
- Check and adjust the tension of wire rope on a regular basis.
- Regularly check all moving parts and make sure there are signs of wear and damage, if any the use of the device must be stopped immediately and contact our after-sales department.
- During inspection, it is necessary to make sure that all bolts and nuts are completely fixed. If any bolt or nut connection is loosened, please re-tighten.
- Check weld for cracks.
- Failure to perform daily maintenance may result in personal injury or equipment damage.

III. ASSEMBLY INSTRUCTIONS


Unpack the carton and place all parts on the floor. Carefully remove all packing material and check each part with the manual. Remember some parts are pre-fitted to larger components.

! IMPORTANT:

Assemble will all nuts and bolts loose at first and only tighten after completing assembly steps.

! NOTE:

Some of the smaller components may be pre-fitted to larger components.
Please check carefully before contacting us regarding any missing components.




STEP 1

a. Assemble the long grounding frame (1), short grounding frame (2) and connecting frame (3), using Screw M12x80(33), Flat washer Φ 12 (35) and Lock nut M12 (39).

b. Connect the stainless steel sliding pipe (14), right sliding frame (11), right pulley frame (5), vertical frame (13), guide rod (12), pulley frame (16), sliding frame (8), Rubber pad (20) and fixing plate (18) together (as shown in figure), using:

- Screw M10X75(26)
- Screw M12X75 (32)
- Screw M12X25 (29)
- Screw M12X80 (33)
- Spring washer ϕ 10 (36)
- Flat washer Φ 10 (34)
- Flat washer Φ 12 (35)
- Lock nut M12 (39)


c. Install the barbell frame (9) and the barbell frame tube (15) on the sliding frame (8), using Screw M10X20 (23) (There are M10 fixing screws inside the barbell bar for fixing this part).



STEP 2

a. Install the handle frame (7) on the upper cross beam frame (6), using Screw M12x30 (30), Flat washer Φ 12 (35) and Spring washer Φ 12 (37).

b. Install the upper cross beam frame (6) on the right pulley frame (5), using Screw M12x30 (30), Flat washer Φ 12 (35) and Lock nut M12 (39).



STEP 3

For the installation steps of the left frame, please refer to installation step 1 for assembly.

a. Install the pulley (21), I baffle (19), spacer (22) and steel cable (17) on the whole machine as shown in the figure, using:

- Screw M10x120 (28)
- Screw M10x95 (27)
- Screw M10x70 (25)
- Screw M10x45 (24)
- Flat washer $\Phi 10$ (34)
- Lock nut M10 (38)

IV. PARTS LIST

No.	Description	Qty	No.	Description	Size	Qty
1	Long Grounding Frame	2	21	Pulley		18
2	Short Ground Frame	2	22	Spacer		4
3	Connecting Frame	2	23	Screw M10X20		2
4	Left Pulley Frame	1	24	Screw M10X45		10
5	Right Pulley Frame	1	25	Screw M10X70		2
6	Upper Cross Beam Frame	1	26	Screw M10X75		4
7	Handle Frame	1	27	Screw M10X95		2
8	Sliding Frame	2	28	Screw M10X120		2
9	Barbell Frame	4	29	Screw M12X25		4
10	Left Sliding Frame	1	30	Screw M12X30		6
11	Right Sliding Frame	1	31	Screw M12X70		2
12	Guide Rod	4	32	Screw M12X75		8
13	Stand	2	33	Screw M12X80		16
14	Stainless Steel Sliding Tube	2	34	Flat Washer Φ 10		36
15	Barbell Frame Tube	2	35	Flat Washer Φ 12		66
16	Pulley Frame	2	36	Spring washer Φ 10		4
17	Wire Rope	2	37	Spring washer Φ 12		6
18	Fixed Plate	4	38	Lock Nut M10		16
19	L Baffle	6	39	Lock Nut M12		30
20	Rubber Pad	4				

V. EXERCISE GUIDE

! PLEASE NOTE:


Before beginning any exercise program, consult your physician. This is important especially if you are over the age of 45 or individuals with pre-existing health problems.

The pulse sensors are not medical devices. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as an exercise aid in determining heart rate trends in general.

Exercising is great way to control your weight, improving your fitness and reduce the effect of aging and stress. The key to success is to make exercise a regular and enjoyable part of your everyday life.

The condition of your heart and lungs and how efficient they are in delivering oxygen via your blood to your muscles is an important factor to your fitness. Your muscles use this oxygen to provide enough energy for daily activity. This is called aerobic activity. When you are fit, your heart will not have to work so hard. It will pump a lot fewer times per minute, reducing the wear and tear of your heart.

So as you can see, the fitter you are, the healthier and greater you will feel.



WARM UP


Start each workout with 5 to 10 minutes of stretching and some light exercises. A proper warm-up increases your body temperature, heart rate and circulation in preparation for exercise. Ease into your exercise.

After warming up, increase the intensity to your desired exercise program. Be sure to maintain your intensity for maximum performance. Breathe regularly and deeply as you exercise.

COOL DOWN

Finish each workout with a light jog or walk for at least 1 minute. Then complete 5 to 10 minutes of stretching to cool down. This will increase the flexibility of your muscles and will help prevent post-exercise problems.

WORKOUT GUIDELINES



! This is how your pulse should behave during general fitness exercise. Remember to warm up and cool down for a few minutes.

VI. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au.

Please visit our website to view our full warranty terms and conditions:
<http://www.lifespanfitness.com.au/warranty-repairs>

WARRANTY AND SUPPORT

Any claim against this warranty must be made through your original place of purchase. Proof of purchase is required before a warranty claim may be processed.

If you have purchased this product from the Official Lifespan Fitness website, please visit <https://lifespanfitness.com.au/warranty-form>

For support outside of warranty, if you wish to purchase replacement parts or request a repair or service, please visit <https://lifespanfitness.com.au/warranty-form> and fill in our Repair/Service Request Form or Parts Purchase Form.

Scan this QR code with your device to go to lifespanfitness.com.au/warranty-form



CORTEX[®]

WWW.LIFESPANFITNESS.COM.AU