


LSG

RB-1 OWNER'S MANUAL



Product may vary slightly from the item pictured due to model upgrades



Read all instructions carefully before using this product. Retain this owner's manual for future reference.

TABLE OF CONTENTS

1.	IMPORTANT SAFETY INSTRUCTIONS	3
2.	CARE INSTRUCTIONS	4
3.	ASSEMBLY INSTRUCTIONS	5
4.	COMPUTER OPERATION	14
5.	EXERCISE GUIDE	15
6.	EXPLODED DIAGRAM	17
7.	PARTS LIST	18
8.	WARRANTY	19

1. IMPORTANT SAFETY INSTRUCTIONS

WARNING - Read all instructions before using this machine.

It is important your machine receives regular maintenance to prolong its useful life. Failing to regularly maintain your machine may void your warranty.

Please keep this manual with you at all times

- a. It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained and used properly.

Please note: It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.

- b. Before starting any exercise program you should consult your doctor to determine if you have any medical or physical conditions that could put your health and safety at risk, or prevent you from using the equipment properly. Your doctor's advice is essential if you are taking medication that affects your heart rate, blood pressure or cholesterol level.
- c. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, and extreme shortness of breath, lightheadedness, dizziness or feelings of nausea. If you do experience any of these symptoms, you should consult your doctor before continuing with your exercise program.
- d. Keep children and pets away from the equipment. This equipment is designed for adult use only.
- e. Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 2 meters of free space around it.
- f. Before using the equipment, check that the nuts and bolts are securely tightened. If you hear any unusual noises coming from the equipment during use and assembly, stop immediately. Do not use the equipment until the problem has been rectified.

- g. Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may get caught in the equipment or that may restrict or prevent movement.
- h. This equipment is designed for indoor and family use only
- i. Care must be taken when lifting or moving the equipment so as not to injure your back.
- j. Always keep this instruction manual and assembly tools at hand for reference.
- k. The equipment is not suitable for therapeutic use.
- l. The pulse or heart rate sensors are not medical devices. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as exercise aids in determining heart rate trends in general.

2. CARE INSTRUCTIONS

- a. Lubricate moving joints with grease after periods of usage
- b. Be careful not to damage plastic or metal parts of the machine with heavy or sharp objects
- c. The machine can be kept clean by wiping it down using dry cloth
- d. All nuts and bolts are to be checked and tightened on a regular basis. This includes pedals and other moving parts. Failure to do so may cause damage to your thread and void your warranty.

Battery Usage

- a. Batteries are to be installed or replaced by adults only
- b. Do not use rechargeable batteries. Do not mix different battery types. Do not mix old and new batteries.
Do not mix alkaline, standard (Carbon-Zinc), or rechargeable (Nickel-Cadmium) batteries
- c. Remove batteries when product is not in use

- d. Remove exhausted batteries from product and dispose of in accordance with the manufacturer's recommendation
- e. Do not attempt to recharge non-rechargeable batteries
- f. Batteries are to be inserted with correct polarity
- g. The supply terminals are not to be short-circuited
- h. Do not dispose of batteries in fire, batteries may explode or leak



3. ASSEMBLY INSTRUCTIONS

Tools

Most of the listed assembly hardware has been packaged separately, but some hardware items have been preinstalled in the identified assembly parts. In these instances, simply remove and reinstall the hardware as assembly is required.


Please reference the individual assembly steps and make note of all preinstalled hardware

Preparation

Prior to assembly, make sure that you will have enough space around the item; Use the present tooling for assembly; before assembling please check whether all needed parts are available.


It is strongly recommended this machine to be assembled by two or more people to avoid possible injury.

STEP 1:




1. Attach the front stabilizer (8) to the front main frame (1) with the carriage bolts (9), arc washers (10) and acorn nut (11) as shown.
2. Attach the rear stabilizer (6) to the rear main frame (2) with the carriage bolts (9), arc washers (10) and acorn nut (11) as shown

STEP 2:




1. Connect the pulse connecting wires (32) and (33).
2. Pull up the knob (16), then attach the rear main frame (2) to the front main frame (1) with knob (16). Once desired setting is reached, tighten the knob (16).

STEP 3:




1. Attach the seat (25) and back rest (24) to the Seat frame (3) with the Allen bolt (21) and flat washers (22).

STEP 4:




1. Attach the Seat frame (3) to the rear main frame (2) with the Allen bolt (21) and flat washers (22).

STEP 5:



1. Connect the pulse sensor wire (20) to the pulse connecting wire 1 (32).
2. Attach the handlebar (4) to the seat frame (3) with carriage bolt (17), flat washer (18) and acorn nut (11) as shown.



STEP 6:



1. Attach the pedal (7L/R) to the crank (5).


NOTE: Ensure that right pedal, marked (R), is attached to the right crank arm (R), It should be tightened in the clockwise direction. The left pedal, marked (L), is to be attached to the left crank arm (L) and it should be tightened in the counter-clockwise direction.

STEP 7:



1. Connect the sensor wire (34) and pulse connecting wire 2 (33) with the extension sensor wire (37) and pulse connecting wire 3 (38).
2. Pull out the lower tension control cable (48) from the bottom of handlebar post (39) to the hole of tension controller. Connect the wire of tension controller (27) with the lower tension control cable (48) as shown above. Attach the tension controller (27) to the handlebar post (39) with cross screw (31), flat washer (30) and tension controller cover (29).
3. Attach the handlebar post (39) to the main frame (1) with the allen bolt (40) and arc washer (41).

STEP 8:



1. Attach the handlebar (42) to the handlebar post (39) with the bolt (44), handle cover (45), bushing (46) and flat washer (47).
2. Connect the extension sensor wire (37) and pulse connecting wire 3 (38) with the wire from computer (28). Then attach the computer (28) to the computer bracket on the handlebar post (39) with cross screws (36).
3. Buckle the rope (35) to the front stabilizer (8).

4. COMPUTER OPERATION

PROGRAM PARAMETERS

TIME	00:00-99:59
SPEED	0.0-99.9km/h
DISTANCE	0.00-999.9km
CALORIES (CAL)	0-999.9kcal
ODOMETER (if included)	0-9999km
PULSE (if included)	40-240bpm

KEY FUNCTIONS:

MODE: This key lets you to select and lock on to a desired function.

SET (if included): Sets data for "TIME", "DISTANCE", "CALORIES".

CLEAR (RESET): Resets the value to zero.

※ON/OFF(START/STOP): Pauses signal input.

OPERATION PROCEDURES:

1. AUTO ON/OFF:

- ◆ The system turns on when any key is pressed or when it receives a signal input from the speed sensor.
- ◆ The system turns off automatically when the sensor has no signal input or no key is pressed for approximately 4 minutes.

2. RESET:

The unit can be reset by either changing the battery or pressing the mode key for 3 seconds.

3. MODE:

Choose either the SCAN or LOCK function. When in SCAN mode, wait for the pointer to reach the desired function then press the MODE key to lock the pointer

FUNCTIONS:

TIME: Press the MODE key until the pointer advances to TIME. The total working time will be shown.

SPEED: Press the MODE key until the pointer advances to SPEED. The total working time will be shown.

DISTANCE: Press the MODE key until the pointer advances to DISTANCE. The distance of each workout will be displayed.

ODOMETER (if included): Press the MODE key until the pointer advances to ODOMETER. The total accumulated distance will be shown.

PULSE (if included): Press the MODE key until pointer advances to PULSE. User's current heart rate will be displayed in beats per minute. Place the palms of your hands on both of the contact pads (or put ear-clip to ear), and wait for 30 seconds for the most accurate reading.

Please Note: Pulse data is for reference only and should not be used for medical purposes.

CALORIES: Press the MODE key until the pointer advances to CALORIES. The calories burned will be displayed.

SCAN: The computer will automatically cycle through the display functions every 4 seconds

BATTERY

This monitor uses one or two (if pulse is included) AA batteries. If the display shows incorrectly, please replace the batteries.

5. EXERCISE GUIDE

PLEASE NOTE: Before beginning any exercise program, consult your physician. This is important especially if you are over the age of 45 or individuals with pre-existing health problems.

The pulse sensors are not medical devices. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as an exercise aid in determining heart rate trends in general.


Exercising is a great way to control your weight, improve your fitness and reduce the effect of aging and stress. The key to success is to make exercise a regular and enjoyable part of your everyday life. The condition of your heart and lungs and how efficient they are in delivering oxygen via your blood to your muscles is an important factor to your fitness.

Your muscles use this oxygen to provide enough energy for daily activity. This is called aerobic activity. When you are fit, your heart will not have to work so hard. It will pump a lot fewer times per minute, reducing the wear and tear of your heart.

So as you can see, the fitter you are, the healthier and greater you will feel.

Warm-up

Start each workout with 5 to 10 minutes of stretching and some light exercises. A proper warm-up increases your body temperature, heart rate and circulation in preparation for exercise. Ease into your exercise.



Training Zone Exercise


After warming up, increase the intensity to your desired exercise program. Be sure to maintain your intensity for maximum performance. Breathe regularly and deeply as you exercise.

Cool Down

Finish each workout with a light jog or walk for at least 1 minute. Then complete 5 to 10 minutes of stretching to cool down. This will increase the flexibility of your muscles and will help prevent post-exercise problems.

Workout Guidelines


TARGET ZONE



This is how your pulse should behave during general fitness exercise. Remember to warm up and cool down for a few minutes.

The most important factor here is the amount of effort you put in. The harder and longer you work, the more calories you will burn.

6. EXPLODED DIAGRAM



7. PARTS LIST

NO.	DESCRIPTION	Q'TY	NO.	DESCRIPTION	Q'TY
1	Front main frame	1	25	Seat	1
2	Rear main frame	1	26	Round end cap	4
3	Seat frame	1	27	Tension controller	1
4	Handlebar	1	28	Computer	1
5	Crank	1	29	Tension controller cover	1
6	Rear stabilizer	1	30	Flat washer	1
7 L/R	Pedal (L/R)	1pr.	31	Cross screw	1
8	Front stabilizer	1	32	Pulse connecting wire 1	2
9	Carriage bolt	4	33	Pulse connecting wire 2	2
10	Arc washer	4	34	Sensor wire	1
11	Acorn nut	6	35	Rope	2
12	Front end cap	2	36	Cross screw	4
13	Rear end cap	2	37	Extension sensor wire	1
14	Square end cap	1	38	Pulse connecting wire 3	2
15	Bushing	1	39	Handlebar post	1
16	Knob	1	40	Allen bolt	4
17	Carriage bolt	2	41	Arc washer	4
18	Flat washer	2	42	Handlebar	1
19	Foam grip	2	43	Foam grip	2
20	Pulse sensor wire	2	44	Bolt	1
21	Allen bolt	12	45	Handle cover	1
22	Flat washer	12	46	Bushing	1
23	Square end cap	2	47	Flat washer	1
24	Backrest	1	48	Lower tension control cable	1

8. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au

Please visit our website to view our full warranty terms and conditions:

<http://www.lifespanfitness.com.au/warranty-repairs>

Warranty and Support:

Please email us at support@lifespanfitness.com.au for all warranty or support issues.

For all warranty or support related enquiries an email must be sent before contacting us via any other means.