

KINGSMITH WalkingPad Treadmill User Manual

For security purpose, please read the User Manual carefully.



Manufacturer: Beijing Kingsmith Technology Co., Ltd.

Address: Floor 4, Building 25, Area 18, ABP Park, Fengtai, Beijing, China.

MADE IN CHINA

Model No. : *TRR1F / TRR1F Pro*

WalkingPad

KING SMITH



IMPORTANT SAFETY INSTRUCTIONS

The appliance is intended for household.



DANGER – To reduce the risk of electric shock:

Always unplug this appliance from the electrical outlet immediately after using and before cleaning.



WARNING – To reduce the risk of burns, fire, electric shock, or injury to persons:

- 1) An appliance should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
- 2) Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- 3) Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- 4) Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- 5) Do not carry this appliance by supply cord or use cord as a handle.
- 6) Keep the cord away from heated surfaces.
- 7) Never drop or insert any object into any opening.
- 8) Do not use outdoors.
- 9) Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- 10) To disconnect, turn all controls to the off position, then remove plug from outlet.

IMPORTANT SAFETY INSTRUCTIONS



- 1. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 2. Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.


WARNING: keep young children away from this machine at all times. Contact with the moving surface may result in severe friction burns.

Contents

01. Product and Accessories	02
02. Function Diagram	03
03. Initial Operating Guide	07
04. Learn to Use the Treadmill	09
05. Trademark and Legal Notice	12
06. Safety Instruction	13
07. Maintenance and Repair	16
08. Replacement and Disposal	17

Welcome


Thank you for choosing KINGSMITH WalkingPad Treadmill, and hereinafter referred to as "Treadmill". The exquisite, simple and innovative design enable you to enjoy your quality and enjoyable workout at home. This Treadmill is designed for family use only. Please do not use it for any business, lease or public group purpose.



Preference Index	Parameter
Applicable Age	14-60 years old
Speed Range	Walking Mode: 0.5-6km/h(0.5-3.7mi/h) Running Mode: 0.5-10km/h(0.5-6.2mi/h)
Running Area	440×1200 mm (17"×47" in)
Max Load	110 kg (240 lbs)
Frequency	50/60 Hz
Voltage	220-240 V~
Power Input	918 W
Net Weight	33 kg (72 lbs)
Unfold Size	1460×720×900 mm (57.5"×28"×35.5" in)
Folded Size	980×720×155 mm (38.5"×28"×6" in)
Working Mode	Running Mode/Walking Mode
Noisy Level	65dB(A)

01. Product and Accessories

Please check if the items inside the packaging box are complete and intact. In case of any missing or breakage, please contact saler.



Treadmill

Accessories



Power line



Remote control



Remote control
lanyard




Hex L
Shaped Wrench



Safe Lock



Silicone Oil




User Manual

02. Function Diagram


1. Walking Mode

Handrail is horizontal when treadmill is on walking mode. Max speed of this mode is 6km/h. On this mode, can use manual mode (M) and automatic mode (A). It has 3km/h speed limit when first time use the treadmill. Three approaches can unlock limited of speed to 6km/h: Finish beginner guidance on APP which named KS Fit, walking on treadmill for 1km, setting limited speed on "KS Fit" APP.




2. Running Mode

Handrail is vertical when treadmill is on running mode. Max speed of this mode is 10km/h. On this mode, can use manual mode (M). According to safety, running mode do not support automatic mode (A).




02. Function Diagram


3. Function of Display Panel




4. Remote Control




03. Initial Operating Guide




1. When moving, make sure that all of the locking devices of handrail are locked and fixed. Please put treadmill in a flat and firm ground, instead of the soft cushion or thick carpets.




3. Unfold the treadmill, adjust the walking belt to the center position, slowly unfold it and assist in pressing it down to make it completely flat, or rotate the bottom foot cushion for leveling.




2. Loose the handrail locking device, lift the handrail to a vertical angle, Tighten the two locking devices on both sides of handrail.




4. Adjust the handrail quick mounting device to a suitable height, and then lock the device. Marks in yellow on handrail are the maximum and minimum adjustable positions.



5. Install emergency stop switch, Connect power supply, and turn on power switch.



7. Open APP, follow the guide to add and bind the treadmill, then ready to use the treadmill.



6. Download "KS Fit" APP from Apple Store or Google Play Store and complete installation.

04. Learn to Use the Treadmill

1. Mode Description



Standby Mode

The standby mode indicator lights up, the motor and sensor are stoped.



Manual Mode

The manual mode indicator lights up, control the speed via remote control or APP.



Automatic Mode

The automatic mode indicator lights up, control the speed automatically via intelligent algorithm.

2. Standby Mode Control Description




Standby Mode

Under standby mode, users can press the mode button on the remote control briefly to wake up the treadmill and switch to the default manual mode state.

Users can also touch the other icon on the display panel to wake up the treadmill.

When the treadmill is not operating, press the mode button on the remote control or touch the standby icon on the display panel to switch to the standby mode.



Remote Control Diagram

Short press: Mode switch


Long press: Switch to standby mode (non-operational state)

3. Manual Mode Control Description(primary mode)



Manual Mode

In this mode, users can use the remote control to control the treadmill. Beginners are advised to use the manual mode first, and then use the automatic mode after being skilled.



Mode Button

Short press: Mode switch

Long press: Switch to standby mode (non-operational state)

Speed Increase Button

Short press: Speed increased by 0.5 km/h (0.5 mi/h)

Function Button

Short press: Boot or stop the treadmill

Speed Decrease Button

Short press: Speed decreased by 0.5 km/h (0.5 mi/h)

04. Learn to Use the Treadmill


4. Automatic Control Mode Description



Automatic

This mode is difficult to control and can be used completely without the remote control. It is advised to use this mode after proficiency. Use the remote control to start and stop, and the mode switch button is effective under this mode.

Note: The automatic control mode can only available under walking mode.



05. Trademark and Legal Notice

5. Remote Control Paring Instructions

If the remote control does not respond or you have replaced the remote control, you need to re-pair. Pairing method: Restart the machine and press the mode button on the remote control for 5 seconds.

6. Connection Caution Light

Not connected to APP: Flicker
Connected to APP: Off


7. Fault Caution Light

E01: Software overcurrent	E08: Sensor fault
E02: Hardware overcurrent	E09: Motor unable to start
E03: IPM Module Overheating	E12: Motor overcurrent protection
E04: Low-voltage Protection	E13: Overloading protection
E05: Overvoltage Protection	E14: Hall signal loss
E06: Motor phase loss protection	E15: Communication fault
E07: Motor block rotation protection	


The patents involved in Kingsmith WalkingPad Treadmill series products are made by Beijing Kingsmith Technology Co., Ltd. and owned by the Company. No organization or individual may copy, distribute all or any part of this manual without Kingsmith's written permission, and may not use these patents without authorization.

When printing this manual, we have put various functional descriptions and instructions in it as far as possible. However, due to the continuous improvement of product functions and design changes, there may still be discrepancies with the products you purchased. Due to product update, this manual may deviate from the actual product in terms of color, appearance, etc. Please refer to the actual product.


06. Safety Instruction





⚠ The distance behind the treadmill should be kept above 2000mm. You can hold the handrail tightly to support your body and jump away from the treadmill.



⚠ The distance between the two sides of the treadmill should be kept above 500mm.




⚠ Please wear sports shoes and clothes and exercise moderately when using the treadmill. If you feel uncomfortable during running, please stop immediately and consult a doctor. Otherwise, you may have risk of injury.




Actuator release force: 7N
Clamp release force: 18N

⚠ Test the safe lock before using treadmill. Please clamp the end of the safe lock on clothes when running on the treadmill. If there is an unexpected situation, pull off the safe lock to stop the treadmill immediately.




⊗ Do not operate treadmill in damp or wet locations. Do not use it on an irregular ground.




⚠ Please unplug the power cord when not in use.




⊗ Do not step on the head of the treadmill.



⊗ Do not bring pets when using.




⊗ Do not use the treadmill upside down or sideways.




⚠ Use with caution for the elderly, children and pregnant women.


06. Safety Instruction




⚠ Watch your hands.




⚠ Take care of your belongings.



⊗ Do not fold before power off.




⚠ Keep treadmill upright and put it in the space with supporting points on both sides as far as possible, please stay away from children.



⊗ Do not get on and off the machine when treadmill operating.


07. Maintenance and Repair

1. Clean the treadmill




- Disconnect all power before cleaning the treadmill.
- Add a little mild detergent to the 100% cotton cloth. Do not spray the detergent directly on the walking belt or use acidic and corrosive detergent.
- Do not wipe under the walking belt
- After a period of exercise, dust and stains may appear on the rear floor. This is normal and just wipe.

2. Walking Belt Slipping and Correction



- Start the treadmill and run at a speed of 3 km/h (2 mi/h) .
- Walking belt to the left: Turn the left adjusting hole screw clockwise by 1/4 turn.
- Walking belt to the right: Turn the right adjusting hole screw clockwise by 1/4 turn.
- Walking belt slipping: Turn the left and right adjusting screws clockwise for 1/2 turn at the same time.
- After each adjustment, it needs to run for a period of time (1-2 minutes) to observe the correction. Please adjust again if necessary.

3. Walking belt lubrication



- Power off the treadmill and unplug the power line.
- Lift the edge of the walking belt and smear the inner surface with silicone oil.
- Start the treadmill to run at a speed of 3 km/h (2 mi/h) for 10-20 seconds.
- 5-10ml of silicone oil is required for each lubrication. Excessive silicone oil may cause slipping and affect normal use.
- Lubricate your walking belt every three months.

08. Replacement and Disposal



The battery contained in this appliance must be removed for or disposal.

When replacing the battery, use only original battery, available from our online parts shop.

The battery compartment is located on the underside of the appliance. Open the compartment by removing the screw in the cover using a suitable screwdriver, and then press the lower end of the locking catch on the connectors. In that way, both sides of the connection can be separated by pulling them apart.

When inserting a new battery, push together the two connectors and ensure that the catch locks over the stop.

Never dispose of old battery in domestic garbage, but only through the proper public collection points. This also applies to the battery of defective appliances.



Devices marked with this symbol must be disposed of separately from your household waste, as they contain valuable materials which can be recycled. Proper disposal protects the environment and human health. Your local authority or retailer can provide information on the matter.