





LIFESPAN KIDS

USER MANUAL

Yardtopia Maryborough 3m x 3.6m Timber & Steel Roof Gazebo Set



Find the Digital
Manual Online



*YT004 & YT005 & YT006 & YT007 3x3.6m Yardtopia Maryborough Timber & Steel Roof Gazebo



WARNING: The disassembled product may contain small parts which pose a choking hazard to children under 3.

IMPORTANT:

This product may contain sharp points and small parts prior to assembly. The owner's manual contains safety, assembly, use and maintenance instructions. This product must be assembled by an adult who has read and understood these instructions. Keep the packaging away from children and dispose of all packaging before use.

For the installer and your children's safety, it is important to fully read and understand the instructions and safety hazards before commencing the assembly of the product.

NOTE:

This manual should not be used to guide your purchasing decision. Your product, and the contents inside its carton, may vary from what is listed in this manual. This manual may also be subject to updates or changes. Updated manuals are available through our website at www.lifespankids.com.au.

TABLE OF CONTENTS

I. SAFETY WARNINGS AND MAINTENANCE INSTRUCTIONS	3
II. PREPARATION	4
III. SET UP DIMENSIONS	5
IV. PARTS LIST	6
V. ASSEMBLY INSTRUCTIONS	10
VI. WOOD ADVICE	54
VII. CLEANING	56
VIII. WARRANTY	56

I. SAFETY WARNINGS AND MAINTENANCE INSTRUCTIONS

IT IS IMPORTANT TO CHECK AND TIGHTEN ALL HARDWARE AT THE BEGINNING AND DURING THE SEASON AS THEY MAY LOOSEN DUE TO WOOD EXPANSION AND CONTRACTION.

Important: Owners are responsible for maintaining the legibility of warning labels. Retain this manual for future reference on maintenance instructions.

- **Do not climb or walk on the roof** for any reason.
- **Assembly requires two or more people** to ensure safety.
- Before digging or driving stakes into the ground, **check for underground utilities**.
- **Check and tighten all hardware regularly**, especially at the start and during the season, as wood may expand and contract over time.
- Carefully check for overhead lines, ensuring there is at least **6 feet (2 meters) of clearance from electrical wires**.
- **Building permits** may be required for permanent structures. As the purchaser or installer, consult local planning, zoning, and building inspection departments to confirm compliance with applicable building codes and zoning regulations.
- **Wood is not fire-retardant** and will burn. Grills, fire pits, and chimineas pose a fire hazard if placed too close to the structure.
- **Wear gloves** during installation to prevent injury.
- Follow all safety warnings provided with your tools, and **wear safety glasses** during installation.
- Check and tighten all nuts and bolts **twice a month during the usage season**. Be careful not to overtighten to avoid damaging the wood. Pay special attention at the beginning of each season.
- **Oil all metallic moving parts** monthly during the usage season.
- Inspect all bolt coverings and sharp edges **twice a month** to ensure they are securely in place and replace them if necessary—especially at the start of each season.
- Surface rust or rust can occur when protective coatings are scratched or in high salt or moisture content areas. To minimize this condition, if any scratch surfaces appear, immediately touch up with rust inhibiting paint.
- For rusted areas on metallic parts like hinges or brackets, **sand and repaint using non-lead-based paint**. Do not leave any surface rust unattended as the oxidation can worsen and will make it difficult to remove the rust later on.
- **Inspect wood parts monthly**. In dry seasons, wood grain may lift, creating splinters. Lightly sand any rough areas to maintain a safe environment. After sanding, apply a protective sealant to prevent severe weather damage, checking, or splitting.
- The unit is stained with a waterborne translucent finish for colour only. To protect the wood, you must apply a sealant **once or twice a year**, depending on your climate. Before applying, lightly sand any rough spots. This maintenance is required to keep your warranty valid.
- Do not use any abrasive cleansers for the **cleaning**. Use a soft, damp cloth to eliminate dirt and dust.

II. PREPARATION

Placement of Product

It is critically important to start with square and level footings, a concrete pad, or a ground when attaching your structure.

- Pay close attention to the items required for each step. Ensure you are using the correct hardware for each step, as using incorrect hardware may result in improper assembly.
- Always double-check for underground utilities and overhead electrical lines before proceeding.
- Check the concrete surface is not damaged and structurally compliant. The thickness of the concrete base is required to be around 100mm.

Owner's Manual: Basic Setup Dimensions & Assembly Notes

Post mounts are provided with your structure to allow for permanent installation on a pre-existing concrete surface.


- Hardware to attach the post mounts to the structure is included.
- Hardware to mount the structure permanently to a concrete surface is **not** included and must be purchased separately.
- Hardware to mount the structure permanently to a wood deck is **not** included. Ensure there is sufficient structural support under the deck before attaching the structure permanently.

Metal Roof Assembly


- Place roofing materials on a non-abrasive, flat surface both before and after assembly to avoid bending, denting, or scratching.

Before you start:

1. Please read all instructions carefully.
2. Separate and count all parts and hardware.
3. Ensure weather conditions are good for the whole day as this may take a few hours for installation.
4. Keep all small parts away from children and pets as they can pose a choking hazard.




III. SET UP DIMENSIONS




IV. PARTS LIST

01 4pcs



02 4pcs



04 8pcs



05 4pcs




A1 4pcs



F1 4pcs




B1 6pcs



H2 2pcs




D1 2pcs



H6 2pcs



D2 2pcs



H7 2pcs



E1 2pcs




H8 2pcs



E2 2pcs




H9 2pcs



E3 2pcs




I5 2pcs






E4 2pcs




I6 2pcs







T1 4pcs




T7 4pcs




T12 4pcs




T18 4pcs




T13 4pcs




T17 4pcs




T14 4pcs




T16 4pcs




























T8 2pcs





T15 2pcs



AA	8pcs	M8X165	
BB	40+ 4pcs	M5X30	
CC	8pcs	M10X80	
DD	8pcs	M6X70	
EE	12+ 2pcs	M5X40	
FF	20+ 1pcs	M8X25	
GG	14+ 2pcs	M6	
HH	16pcs	M8X60	
JJ	16+ 1pcs	M5X20	
KK	12+ 1pcs	M6X55	
LL	20+ 2pcs	M6X45	
MM	22+ 1pcs		
NN	2+ 1pcs	M6X25	
TT	138+ 14pcs	M6X15	
UU	16pcs	6X200	
PP	8pcs	M10X80	
X5	4pcs		
Y1	1pc	M6	
Y2	1pc	M16	
Y3	2pcs	M10	
Y4	2pcs	M8	
Y5	2pcs	M8	
Y6	2pcs	M6	
Y7	1pc	M6	
Y8	1pc	M8	

V. ASSEMBLY INSTRUCTIONS


STEP 1



02 4pcs



Z6 2pcs





X3 4pcs




M8*25

FF 12pcs

STEP 2



05 4pcs






X5 4pcs



M5X20

JJ 16pcs

STEP 3



AA 4pcs

M8X165


CC 4pcs

M10*80


M2 4pcs

STEP 4


2pcs



First pre-install bolts HH (do not tighten), then tighten bolts DD on timber 04 and 05. Finally tighten the pre-installed screws DD.





2pcs

 (04) 4pcs

 (DD) 4pcs
M6*70

 (HH) 8pcs
M8X60

STEP 5



01 4pcs



Z3 2pcs



X4 4 pcs




M8*25

FF 8pcs




STEP 6

Slot the part 01 into the brackets on part 02.

Note the direction of the middle tabs (Z2) must face inwards.



STEP 7



M8X145

AA 4pcs



M10*80



CC 4pcs

STEP 8


$\angle R = 90^\circ$

$Y1 = Y2$

Check the frame is $Y1 = Y2$ by measuring from one post to the opposite post diagonally and also the angles of the legs are at 90 degree angles.



04 4pcs



M6*70



DD 4pcs



M8X60

HH 8pcs

STEP 9





(N1) 4pcs



(EE) 12pcs
M5X40

STEP 10



(B1) 4pcs



(Z2) 4pcs





M6X15


(TT) 8pcs

STEP 11

Warning: Gloves should be worn when handling steel roof pieces and sheets.



D2 2pcs






D1 2pcs





TT 8pcs



STEP 12



STEP 13



STEP 14



A1 4pcs






M6X15

TT 24pcs

STEP 15

Push down until it locks into the hole on D1.





F1 4pcs



L1 1pc

STEP 16



Ⓜ15 2pcs

Ⓜ M6X15




Ⓜ16 2pcs



Ⓜ TT 4pcs

STEP 17


Arrange your roof sheets in
the following order.




STEP 18



(T1) 2pcs






(T7) 2pcs




(T8) 2pcs

STEP 19




(T1) 2pcs



(T7) 2pcs

STEP 20



Secure the screws (KK) on to S1 and S2.



(S1) 4pcs




M6*55

(KK) 12pcs



(S2) 4pcs

STEP 21





S1 4pcs




GG 4pcs

STEP 22

Attach the screws underneath and screw in the hook (Q2).



(L2) 1pc




(GG) 2pcs




(Q2) 1pc





STEP 23




STEP 24






Pre-install the screws
but do not tighten.

 <p>(K16) 2pcs</p>	 <p>(K17) 2pcs</p>
 <p>(K14) 2pcs</p>	 M6X15 <p>(TT) 12pcs</p>


STEP 25








STEP 26




STEP 27



Pre-install the screws but do not tighten.


 <p>(K1) 2pcs</p>	 <p>(K2) 2pcs</p>	
 <p>(K3) 2pcs</p>	 <p>(K4) 2pcs</p>	 M6X15 <p>(TT) 16pcs</p>

STEP 28



Arrange your parts in the following order for installing in the next step.

STEP 29



Pre-install the screws but do not tighten.



(H9) 2pcs




(Z4) 4pcs




M6X15

(TT) 4pcs

STEP 30



Pre-install the screws but do not tighten.



(H6) 2pcs




(Z4) 2pcs



M6X15

(TT) 2pcs

STEP 31



Place H8 under H6 and pre-install screws. Do not fully tighten screws at this stage.




(H8) 2pcs



(TT) 2pcs

M6X15

STEP 32



STEP 1
Insert H2 to H6 and pre-install screws. Do not full tighten screws at this stage.

STEP 2
Place H2 under H7 and pre-install screw. Do not full tighten screws at this stage.

STEP 1
Insert H7 to H9 and pre-install screws. Do not full tighten screws at this stage.



(H7) 2pcs



(H2) 2pcs




(TT) 2pcs

M6X15

STEP 33

Pre-install the screws but do not tighten yet.



(E1) 2pcs




(E2) 2pcs


 M6X15

(TT) 8pcs


STEP 34



Pre-install the screws but do not tighten.



E3 2pcs




E4 2pcs



TT 8pcs

M6X15

STEP 35




Tighten all the pre-installed screws from previous step.


M5X30


BB 8pcs

STEP 36








Arrange the roof sheets to the following order for next installation step.




STEP 37



Start from the middle and work your way out.
Overlap the sheeting by one ridge.

 <p>T12 2pcs</p>	 <p>T13 2pcs</p>
 <p>T14 2pcs</p>	 <p>T15 2pcs</p>
 <p>T16 2pcs</p>	 <p>T17 2pcs</p>
 <p>T18 2pcs</p>	

STEP 38



M6X45

LL


12pcs









MM

12pcs


STEP 39









Start from the middle and work your way out.
Overlap the sheeting by one ridge.

 <p>(T12) 2pcs</p>	 <p>(T13) 2pcs</p>
 <p>(T14) 2pcs</p>	 <p>(T16) 2pcs</p>
 <p>(T17) 2pcs</p>	 <p>(T18) 2pcs</p>

STEP 40





When covering each sheet, pre-install the screws but do not tighten.

  2pcs M6X25	  M6X45 8pcs	  10pcs MM
--	--	--

STEP 41

Secure the Q1 on the middle section where the sheets overlap with the next sheet (T14-T16), (T14-T15), (T15-T16).




Q1 6pcs



TT 12pcs
M6X15

STEP 42



Place the S2 pieces on the corners on the frame (4x) and secure bolts under roof.




S2 4pcs



GG 8pcs


STEP 43



(X1) 8pcs





(X2) 8pcs



(BB) 32pcs

M5X30


STEP 44



Anchoring:

Use **(1)** installation diagram and part UU if you are mounting to dirt ground.

Important: Ensure the ground does not have loose soil and rocks that may get in the way of anchoring. Clear any debris in the area.



Instructions:

1. Hammer the stakes directly into the ground.

Use **(2)** installation diagram and part PP if you are mounting on a concrete base.

Important: Ensure the concrete surface where you intend to install the wedge anchors is safe and can support the objects you plan to fasten. Clear any debris in the area.



(PP) 8pcs



(UU) 16pcs

Instructions:

1. First mark your area then drill a hole into the concrete. The bit should be the same diameter as part PP. Ensure the depth of the hole is about a 1/2" deeper than the length of part PP.

2. Remove the dust and debris from the drill holes using brush or vacuum.
3. Insert anchor PP into the holes and tap with hammer to set it firmly in the hole.

4. Tighten the nut and washer onto the exposed thread end of the anchor. Use a wrench or socket set to tighten the nut until it's snug. Be careful not to over-tighten, as this could damage the anchor or the concrete.

VI. WOOD ADVICE

Lifespan Kids uses 100% cedar wood. While we carefully select the highest quality lumber available, wood is a natural product and may be susceptible to weathering, which can affect the appearance of your set.

What Causes Weathering? Does It Affect the Strength of My Product?

One of the primary causes of weathering is the effect of moisture. The moisture content at the surface of the wood differs from that of the interior. As climate conditions change, moisture moves in or out of the wood, causing tension that can result in checking or warping. You can expect the following due to weathering, though these changes will not affect the strength of the product:


1. **Checking** refers to surface cracks in the wood along the grain. A post (4" x 4") is more prone to checking than a board (1" x 4") because there is a greater difference in moisture content between the surface and the interior of thicker wood.
2. **Warping** results from distortions (twisting, cupping) in the original shape of the board and typically occurs from rapid cycles of wetting and drying.
3. **Fading** is a natural process where the wood colour changes due to sun exposure, gradually turning grey over time.

How Can I Reduce Weathering on My Wood Product?

1. Your wood product is coated with a water-based stain, but sunlight will degrade this coating over time. We recommend applying a water repellent or stain annually (consult your local stain and paint supplier for recommended products). It is essential to apply some form of protection (sealant) to the wood. This is a **requirement of your warranty**. Most weathering is a normal consequence of nature and does not affect safety. However, if you believe a part has experienced severe weathering, please contact our customer service department for further assistance.
2. **Inspect wood parts monthly**. During dry seasons, the grain may lift, causing splinters. Light sanding may be necessary to ensure safety. After sanding, applying a protective sealant will help prevent severe checking, splitting, and other weather-related damage.

When should wood cracks be a concern?

Most of the wood splits will never become large enough to affect the reliability and strength of our products, however, there can be rare cases where splits can occur. This happens when a crack develops past the halfway point from the timber, splitting it into two separate pieces. Feel free to contact us with detailed pictures of your product so we can assess and ensure that your playground remains safe.



Dimensional timber contains very little heart wood so less splits can be seen.

Round pole Swing sets are very thick that cracks (shown left) will not affect the strength and durability of our swing sets.

Mould and Mildew

Protecting against mould and mildew on your outdoor equipment is an important step in maintaining your backyard. Mould may develop for several reasons, such as certain weather conditions, improper drainage or infrequent usage. Here we'll share our tips for keeping your outdoor areas free of mould and mildew so that you can enjoy your backyard with peace of mind.

Once you spot mould on your equipment, it's important to start clearing it up straight away. The first step is to scrub it off with soap and water, until all the visible signs of mould are removed. It's important to remember however, that just because you can't see it anymore doesn't mean it's gone.

The next step is to kill off the remaining mould so that it doesn't grow back. Here are a few options, but keep in mind these should be used independently. Don't mix or combine these methods at the same time.

Mould Killer or Removal Spray

You can purchase off-the-shelf removal sprays that destroy mould either indoors or outdoors. For these products, make sure to follow the product instructions as well as wearing protective gloves to avoid contact with skin.

VII. CLEANING

Do not use any abrasive cleansers for the cleaning. Use a soft, damp cloth to eliminate dirt and dust.

VIII. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au.

Please visit our website to view our full warranty terms and conditions:
www.lifespankids.com.au/Warranty-Policy-Kids

WARRANTY AND SUPPORT

Please email us at support@lifespankids.com.au for all warranty or support issues.

For all warranty or support related enquiries, please lodge a support ticket first by sending us an email.
support@lifespankids.com.au.

