


USER MANUAL

Aspendale 3mx3.6m Metal Gazebo Set



Find the Digital
Manual Online



YT033 & YT034 & YT035



WARNING: Minimum three-person assembly. Assemble on level ground. Do not assemble in strong winds. Secure all legs and anchors before use.

IMPORTANT:

This product may contain sharp points and small parts prior to assembly. The owner's manual contains safety, assembly, use and maintenance instructions. This product must be assembled by an adult who has read and understood these instructions. Keep the packaging away from children and dispose of all packaging before use.

For the installer and your children's safety, it is important to fully read and understand the instructions and safety hazards before commencing the assembly of the product.

NOTE:

This manual should not be used to guide your purchasing decision. Your product, and the contents inside its carton, may vary from what is listed in this manual. This manual may also be subject to updates or changes. Updated manuals are available through our website at www.yardtopia.com.au.

TABLE OF CONTENTS

I. SAFETY WARNINGS AND MAINTENANCE INSTRUCTIONS	3
II. PREPARATION	4
III. EXPLODED	5
IV. ASSEMBLY INSTRUCTIONS	7
V. WOOD ADVICE	47
VI. CLEANING	49
VII. WARRANTY	49

I. SAFETY WARNINGS AND MAINTENANCE INSTRUCTIONS

IT IS IMPORTANT TO CHECK AND TIGHTEN ALL HARDWARE AT THE BEGINNING AND DURING THE SEASON AS THEY MAY LOOSEN.



IMPORTANT: Owners are responsible for maintaining the legibility of warning labels. Retain this manual for future reference on maintenance instructions.

- **Do not climb or walk on the roof** for any reason.
- **Assembly requires three or more people** to ensure safety.
- Before digging or driving stakes into the ground, **check for underground utilities.**
- **Check and tighten all hardware regularly**, especially at the start and during the season, as wood may expand and contract over time.
- Carefully check for overhead lines, ensuring there is at least **6 feet (2 meters) of clearance from electrical wires.**
- **Building permits** may be required for permanent structures. As the purchaser or installer, consult local planning, zoning, and building inspection departments to confirm compliance with applicable building codes and zoning regulations.
- **Wood is not fire-retardant** and will burn. Grills, fire pits, and chimineas pose a fire hazard if placed too close to the structure.
- **Wear gloves** during installation to prevent injury.
- Follow all safety warnings provided with your tools, and **wear safety glasses** during installation.
- Check and tighten all nuts and bolts **twice a month during the usage season.** Be careful not to overtighten. Pay special attention at the beginning of each season.
- **Oil all metallic moving parts** monthly during the usage season.
- Inspect all bolt coverings and sharp edges **twice a month** to ensure they are securely in place and replace them if necessary—especially at the start of each season.
- Surface rust or rust can occur when protective coatings are scratched or in high salt or moisture content areas. To minimize this condition, if any scratch surfaces appear, immediately touch up with rust inhibiting paint.
- For rusted areas on metallic parts like hinges or brackets, **sand and repaint using non-lead based paint.** Do not leave any surface rust unattended as the oxidation can worsen and will make it difficult to remove the rust later on.

- **Inspect wood parts monthly.** In dry seasons, wood grain may lift, creating splinters. Lightly sand any rough areas to maintain a safe environment. After sanding, apply a protective sealant to prevent severe weather damage, checking, or splitting.
- The unit is stained with a waterborne translucent finish for colour only. To protect the wood, you must apply a sealant once or twice a year, depending on your climate. Before applying, lightly sand any rough spots. This maintenance is required to keep your warranty valid.
- Do not use any abrasive cleansers for the **cleaning**. Use a soft, damp cloth to eliminate dirt and dust

II. PREPARATION

PLACEMENT OF PRODUCT

It is critically important to start with square and level footings when attaching your structure.


- Pay close attention to the items required for each step. Ensure you are using the correct hardware for each step, as using incorrect hardware may result in improper assembly.
- Always double-check for underground utilities and overhead electrical lines before proceeding.

OWNER'S MANUAL: MOUNTING NOTES

- Anchors are provided for ground anchoring to soil.
- Hardware to mount the structure permanently to a concrete surface is not included and must be purchased separately.
- Hardware to mount the structure permanently to a wood deck is not included. Ensure there is sufficient structural support under the deck before attaching the structure permanently.

METAL ROOF ASSEMBLY


- Place roofing materials on a non-abrasive, flat surface both before and after assembly to avoid bending, denting, or scratching.





BEFORE YOU START

1. Please read all instructions carefully.
2. Separate and count all parts and hardware.
3. Ensure weather conditions are good for the whole day as this may take a few hours for installation.
4. Keep all small parts away from children and pets as they can pose a choking hazard.








III. EXPLODED DIAGRAM

















IV. ASSEMBLY INSTRUCTIONS





















PARTS LIST














Part No.	Quantity	Reference Image
CT01	4	
CT31	2	
CT32	2	
CT33	2	
CT34	2	
XZCT1	4	
XZCT2	4	





Part No.	Quantity	Reference Image
X9	4	
S15	4	
Q7	4	
S5	8	
P2	4	
Z11	1	




Part No.	Quantity	Reference Image
N2	4	
S6	4	
S4	8	
S14	4	
Q8	4	























Part No.	Quantity	Reference Image
A1	4	
B1	4	
D1	2	
D12	2	
E1	2	
E2	2	
E3	2	
E4	2	
F1	4	
H2	2	
H6	2	
H11	2	
H12	2	
I6	2	
I7	2	
K1	2	
K2	2	
K3	2	
K4	2	
K18	2	

Part No.	Quantity	Reference Image
K19	2	 
K20	2	 
K21	2	 
G1	4	
G2	4	
L5	1	
L6	1	
L7	2	
T101	2	
T102	2	



Part No.	Qty	Part Name	Reference Image
Y1	1	M6	
Y2	1	M6	
Y3	2	M10	
Y5	2	M8	

Part No.	Qty	Part Name	Reference Image
Y6	2	M6	
Y7	1	M6	
Y8	1	M8	


Part No.	Quantity	Reference Image
T1	4	
T7	4	
T8	2	
T12	4	
T13	4	
T14	4	
T15	2	
T16	4	
T17	4	
T18	4	

Part No.	Qty	Part Name	Reference Image
CC612	6+1	M6x12	
CC615	188+14	M6x15	
CC615A	16+2	M6x15	
CC625	2	M6x25	
CC645	20+2	M6x45	
CC645H	8+1	M6x45	
CC655	12+2	M6x55	
CC680	2	M6x80	
GG	14+2	M6	
UU	12	6x200	

STEP 1



CT01 x4



N2 x4



X9 x4








M6x15

CC615 x24



STEP 2

x2




STEP 3

x2



S15 x4








CC615A x8



STEP 4

x2

S15 inserts into the tube of CT31/CT32. See arrow for placement.




STEP 5




M6x15
CC615 x4

STEP 6




STEP 7


Check the frame $Y1=Y2$ by measuring from one post to the opposite post diagonally and also the angles of the legs are at 90 degree angles.



$Y1 = Y2$
 $\angle R = 90^\circ$



XZCT1 x4





XZCT2 x4




M6x15
CC615 x16


STEP 8




B1 x4



M6x45
CC645H x8



S6 x4




S4 x8




M6x15
CC615 x8

STEP 9



A1 x4





S5 x8




M6x15
CC615 x8

STEP 10

Do not fully tighten at this stage.




A1 x4




M6x15
CC615 x16

STEP 11



Tighten all the screws to the frame.



NOTE: This step cannot be performed using a pistol drill.



M6x15

CC615 x16





D1 x2



D12 x2

STEP 12






B1 x4





CC615 x16




STEP 13



M6x15
 CC615 x4




STEP 14






STEP 15

WARNING: Gloves should be worn when handling steel roof pieces and sheets.


Arrange your roof sheets in the following order.




STEP 16



T1 x2






T7 x2




T8 x2

STEP 17




T1 x2



T7 x2

STEP 18



Secure the screw (CC655) on to G1 and G2



G2 x4








G1 x4




M6x55
CC655 x12

STEP 19



STEP 20





G1 x4



GG x4

STEP 21

Attach the screws underneath and screw in the hook (Z11).




GG x2




Z11 x1

STEP 22



STEP 23



Pre-install the screws
but do not tighten.




K1 x1



K2 x1



K3 x1




K4 x1



M6x15
CC615 x4

STEP 24

Install the other 3 sides as STEP 23 guide.



K18 x2



K19 x2



K20 x2



K21 x2



K1 x1



K2 x1



K3 x1




K4 x1




M6x15

CC615 x12

STEP 25



Pre-install, just pinch them to prevent the H6/H11 from falling off.



H11 x2



M6x15
CC615 x8




H6 x2





S14 x4


STEP 26




Remove screw CC615. After H2 and H1 are assembled, then reattach screw CC615.



STEP 27



Tighten all the pre-installed screws from previous step.



E1 x2



E2 x2



E3 x2




E4 x2





M6x15
CC615 x16

STEP 28


Arrange the roof sheet to the following order for next installation step.




STEP 29




Start from the middle and work your way out.
Overlap the sheeting by one ridge.




T12 x2




T13 x2




T14 x2




T15 x2



T16 x2




T17 x2



T18 x2

STEP 30





Start from the middle and work your way out. Overlap the sheeting by one ridge.

When covering each sheet, pre-install the screws but do not tighten.




M6x15
CC645 x12


STEP 31




Start from the middle and work your way out.
Overlap the sheeting by one ridge.




T12 x2




T13 x2




T14 x2



T16 x2





T17 x2





T18 x2


STEP 32



STEP 33



T102 x2




T101 x2




M6x15
CC615 x12

STEP 34



Tighten all the pre-installed screws from previous step.




G2 x4



GG x8

STEP 35




Anchoring

IMPORTANT:

- *These anchors are for ground anchors and not suited for decking or concrete slab installation.
- *Before installing, please check the ground is fully leveled and not installed on a slope.
- *Ensure there are no rocks, pipes, cables, or underground utilities that may prevent proper anchoring. Clear any debris in the installation area.

Instructions:

1. Fully assemble and position the gazebo on level, soft ground.
2. Ensure each base plate (X9) sits flat on the ground.
3. Insert ground stakes (UU) through the base plate holes.
4. Hammer stakes vertically into the ground until fully secure.
5. Check the gazebo is stable and posts are vertical.



UU x12

V. WOOD ADVICE

Our products are manufactured from premium timber. Great care is taken in selecting, machining, and treating the timber before it is sold to you.

1. Inspect wood parts monthly. The grain of the wood sometimes will lift in dry periods causing splinters to appear. Light sanding may be necessary to maintain a safe environment. Treating your Product with protection (sealant) after sanding will help prevent severe checking/splitting and other weather damage.

2. The wood is treated via high temperature drying, degreasing and is stained against wood rot and insect damage (Termites not included). This is not a permanent treatment as weather conditions can wear it down. We recommend once or twice a year, depending on your climate conditions, you must apply some type of protection (sealant) to the wood of your unit. Prior to the application of sealant, lightly sand any “rough” spots on your set. Please note this is a requirement of your warranty.

Bear in mind that timber is a natural product and may experience changes throughout the course of its life. It may:


- Develop openings/checks (gaps, slits, apertures, cracks) along the line of the grain.
- Fade as the timber reacts with sunlight.

All woods are hygroscopic, that is, it will absorb or discharge moisture to attain equilibrium with the surrounding atmosphere. Timber openings/checks occur due to the moisture content between internal and outer surfaces of the timber. No two pieces of wood are exactly alike. Each piece has its own characteristics and personality and reacts differently to climate changes. When any wood products are exposed to the elements, it develops ‘wood checks’. A check is the radial separation of the wood fibres running with the grain of the wood. These are caused by the varying temperature and moisture conditions. A check does not affect the strength or durability of the wood or structural integrity of the play set.

WHEN SHOULD WOOD CRACKS BE A CONCERN?

Most of the wood splits will never become large enough to affect the reliability and strength of our products, however, there can be rare cases where splits can occur. This happens when a crack develops past the halfway point from the timber, splitting it into two separate pieces.

Feel free to contact us with detailed pictures of your product so we can assess and ensure that your playground remains safe.



3. Mould and Mildew

Protecting against mould and mildew on your outdoor equipment is an important step in maintaining your backyard. Mould may develop for several reasons, such as certain weather conditions, improper drainage or infrequent usage. Here we'll share our tips for keeping your outdoor areas free of mould and mildew so that you can enjoy your backyard with peace of mind.

Once you spot mould on your equipment, it's important to start clearing it up straight away. The first step is to scrub it off with soap and water, until all the visible signs of mould are removed. It's important to remember however, that just because you can't see it anymore doesn't mean it's gone.

The next step is to kill off the remaining mould so that it doesn't grow back. Here are a few options, but keep in mind these should be used independently. Don't mix or combine these methods at the same time.

Mould Killer or Removal Spray

You can purchase off-the-shelf removal sprays that destroy mould either indoors or outdoors. For these products, make sure to follow the product instructions as well as wearing protective gloves to avoid contact with skin.

Bleach

A solution of bleach and water can also be highly effective in killing mould. For this method, mix the water and bleach on a 1 to 1 ratio, then use a sponge or brush to scrub the affected area. You can also use a higher concentration of bleach for spot treating. After bleach treatment, make sure to rinse off your equipment and allow to dry.

Vinegar

If mould is still lingers after applying bleach or a mould spray, vinegar will be an effective option for removing stubborn remnants. Vinegar will kill most types of mould and is best for nonporous materials like hard plastics or metal. The best method is to fill a spray-bottle with undiluted white vinegar of at least 5% acetic acid. Spray the affected area, then let sit for around an hour. Make sure to thoroughly rinse off afterwards.

For wooden equipment, you can add a coat of paint or stain after it has thoroughly dried.

Some people may find that mould keeps resurfacing after cleaning on certain areas. This can be due to a few reasons, such as poor sunlight. Areas without direct sun are more likely to become damp and take longer to dry off after rain. Consider removing obstacles or rearranging your equipment so that it receives more sunlight, which will also help to kill the mould once it develops.

For more information: www.yardtopia.com.au

VI. CLEANING

Do not use any abrasive cleansers for the cleaning. Use a soft, damp cloth to eliminate dirt and dust.

VII. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at **www.consumerlaw.gov.au**.

Please visit our website to view our full warranty terms and conditions:

<https://yardtopia.com.au/pages/warranty>

WARRANTY AND SUPPORT

Please email us at **support@yardtopia.com.au** for all warranty or support issues.

For all warranty or support related enquiries, please lodge a support ticket first by sending us an email **support@yardtopia.com.au**.

yardtopia

www.yardtopia.com.au