PROGEAR

ZOOM BALANCE BIKE OWNER'S MANUAL





WARNING!

THIS ITEM REQUIRES ASSEMBLY BY AN ADULT. ASSEMBLY INSTRUCTIONS INCLUDED IN THE PACKAGING.

TABLE OF CONTENTS

I. IMPORTANT SAFETY INSTRUCTIONS	3
II. OWNER'S INFORMATION AND RESPONSIBILITY	5
Maintaining Your Bicycle	5
Monthly Service Chart	6
Additional Information Helpful Hints, Special Instructions and Warranty	7
III. BICYCLE ASSEMBLY INSTRUCTIONS	9
IV. WARRANTY	10

I. IMPORTANT SAFETY INSTRUCTIONS

Failure to obey all of the warnings and instructions contained in this manual may result in serious injury, or permanent damage to your bike.

- Always wear a properly fitted and fastened helmet when riding. This is required by law in most states and is an important safely precaution. Failure to wear an approved safely helmet can result in severe injury or death.
- Check your helmet for proper fit and damage before each ride.
- Always obey all traffic laws.
- The purchaser, owner, and/or riders of this cargo bike are directly responsible for knowing and obeying all local, state and federal laws regarding the riding and use of this cargo bike.
- Always ride cautiously, maintaining complete control and a reasonable speed (<20km/h).
- The rider should hold the handlebars and stop before getting on or off.
- Sitting securely when riding.
- Slow down the speed to 10km/h or less before turning the corner, in order to avoid rolling over.
- This bike is not suitable for stunt riding, jumping, competition, or racing.
- Always check that brakes are functioning properly before each ride.
- Only one rider at a time.
- Do not ride at night or in conditions when visibility is impaired, unless you install head lights and tail lights that make you visible to all pedestrians and vehicles.
- Wet weather significantly detracts from brake performance. Always allow a longer distance for safely stopping in the rain, or on a wet or icy road surface.
- This product should not be used by minors without adult supervision.
- Do not modify the bike
- Do not tow or pull with the cargo bike. Do not allow the bike to be towed or pulled.

- Keep fingers away from moving parts and chain.
- Always park in right place.
- Avoid high speed sharp turns, as your bike may tip over.
- Always apply even pressure to both brakes when stopping.
- Some localities require that the owner or rider equip their bike with a horn, bell, or other sound making device to use for warning others of your approach.
- Check handlebar and seat adjustments before riding.
- Check your tires for cuts, exposed casing, casing cords, and proper inflation before each ride.
- Ensure you wear safe footwear and keep loose articles of clothing clear of moving parts on your E-Bike while riding.

SAFETY GUIDE AND USE FOR BALANCE BIKE

- 1. The balance bike is for children aged 2-5 years old.
- 2. The balance bike is prohibited to use on public traffic.
- 3. For safety, regular maintenance on the bike is required. All screws, steering and axles must be checked by an adult.

EQUIPMENT SAFETY INSTRUCTIONS

- 1. Check all the screw and bolts are tight before each use.
- 2. This toy should be used under adult supervision.
- 3. To be used by one rider at a time only.
- 4. For children under 30 kgs only.
- 5. This toy requires skill to avoid falling or collisions, resulting in possible injuries to the user or to third parties. Teach the child how to use the toy correctly and explain possible dangers.
- 6. Instruct child how to brake and stop by lifting slightly the front part of the toy. Ensure the child is competent with the braking techniques before use.
- 7. This item should be used on smooth, level, dry surfaces. Different surfaces may create an impediment.
- 8. Do not use this item on public roads, on or near dangerous zones such as water, stairways or slopes.

NOTE

DO NOT LEAVE UNDER THE RAIN OR IN A WET STORAGE.

USING OUTDOOR

- Never use on a stairway.
- Never user on the road.
- Never use by pulling with another vehicle.
- You must show the child how to brake.
- Always use under adult supervision.
- Always wear a helmet when riding.

The balance bike should be used for training the coordination and balance of the children by playing. By using the balance bike the children can easily get mastery for a normal bicycle.

To reduce the risk of serious personal injury, you should read the instructions in this manual carefully.



There are **warnings** throughout this manual. Follow all warning instructions. Don't risk injury, mechanical failure or damage.

If your bicycle has been supplied in a form not ready for use you must obtain "assembly instructions" from your supplier.

Know how to operate all standard and accessory equipment on the bicycle.

Ensure that anyone who uses the bicycle has been fully instructed in the operation of bicycle functions.

Your bicycle conforms to relevant Australian Standards. Other local regulations may apply. Check with your bicycle retailer.

Many bicycle product manufacturers and suppliers provide additional information on Web sites.

The Bicycle Industry in Australia Web site includes many useful links and other information at: www.bikeoz.com.au

The Cycling Promotion Fund offers helpful hints and links at: www.rideabike.com.au

1. MAINTAINING YOUR BICYCLE

SERVICE AND BASIC MAINTENANCE

Bicycles perform best when they are kept clean, lubricated and serviced regularly.

How much of your bicycle's service and maintenance you can do yourself depends on your level of

CLEANING

Mud and dust can be highly abrasive. Regular cleaning will help maintain your bicycle in good condition.

Always dry and lubricate your bicycle after washing to prevent rust.

LUBRICATION

Keep your bicycle regularly lubricated for good performance and durability. Lubrication reduces friction and helps protect against rust.

All bearings and other moving parts require regular appropriate lubrication:

- Grease type lubrication:- bearings in head stem, wheels, bottom bracket and pedals (requires disassembly refer to your bicycle retailer).
- Oil type lubrication:- Brake and derailleur pivot points and jockey wheels, chain, free wheel.

For advice on appropriate special lubricants, ask your bicycle retailer.

2. MONTHLY SERVICE CHART

Monthly servicing of your bicycle is recommended. This consists of lubrication and adjustment of components.

Use the correct type of lubricants and tools, service the bicycle's components in logical groups and clean before you start.

TYRES AND TUBES

- Clean the tyres and inspect treads for wear.
- Remove any debris from tread or walls.
- Check tyre pressure is correct.
- Replace faulty tubes.

GENERAL

- Check frame alignment and all the tubes for dents or damage.
- Check all bolts and nuts are secure. Tighten bolts with the correct tools.

STORAGE

The best protection for your bicycle is to store it under cover in a dry environment and away from corrosive materials such as battery acid and swimming pool chemicals. Thoroughly dry off your bicycle after use in wet conditions. Wax or lubricate as required.

Failure to follow this procedure may lead to rust and corrosion of metal work.

3. ADDITIONAL INFORMATION HELPFUL HINTS, SPECIAL INSTRUCTIONS AND WARRANTY

3.1 ABOUT YOUR BICYCLE RETAILER

Your bicycle retailer will help you to select bicycle accessories for the kind of riding you wish to do. Bicycle shop staff have the knowledge, tools and experience to give you reliable advice and provide maintenance services. If you have a problem with your bicycle or your riding, talk to your bicycle retailer.

3.2 TOOLS AND BICYCLE ASSEMBLY

Should you intend to undertake maintenance the following tools are considered to be the basic requirement:

- Adjustable wrench 5-10cm
- Adjustable wrench 32cm
- Flat screw driver 15mm
- Phillips head screw driver 15mm
- Allen Key set 2mm-6mm
- Set of open end spanners 7-17mm
- Set of tyre levers

TROUBLESHOOTING CHART

PROBLEM	POSSIBLE CAUSE	REMEDY	
	Inner tube old or faulty	Replace inner tube	
Franciscot ministrus	Tyre tread / casing worn	Replace tyre	
Frequent punctures	Tyre not checked after previous puncture	Remove sharp object embedded in tyre	
	Tyre pressure too low	Correct tyre pressure	
Steering not accurate	Wheels not aligned	Align wheels correctly	
Makkin a saka at	Axle broken	Replace axle	
Wobbling wheel	Wheel out of true	True wheel	

KEEP A RECORD OF YOUR NEW BICYCLE
OWNER:
ADDRESS:
DDAND & CEDIAL NUMBED:
BRAND & SERIAL NUMBER:
MODEL:
FRAME STYLE:
FRAME SIZE:
FRAME COLOUR(S):
WHEEL SIZE:
TYRE SIZE & TYPE:
BRAKE TYPE & BRAND:
TRANSMISSION BRAND:
SADDLE BRAND:
OTHER ACCESSORIES (LIST & BRAND NAMES):
PURCHASED FROM (SHOP NAME):
SHOP ADDRESS:
TEL:
PRICE PAID: \$
Remember the advice about LOCKING YOUR BICYCLE.


A good quality lock is cheap insurance.


III. BICYCLE ASSEMBLY INSTRUCTIONS

The balance bike is pre-assembled in the box.


The steering bar is to be tightened with the accessory screws (see drawing).

To adjust the seat, loosen the but with the spanner and slide the seat pole up or down into the desired location then re-tighten the nut.













IV. WARRANTY

AUSTRALIAN CONSUMER LAW

Many of our products come with a guarantee or warranty from the manufacturer. In addition, they come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Full details of your consumer rights may be found at www.consumerlaw.gov.au.

Please visit our website to view our full warranty terms and conditions: www.progearbikes.com.au/pages/warranty-repairs

WARRANTY AND SUPPORT

Please email us at support@progearbikes.com.au for all warranty or support issues.

For all warranty or support related enquiries, please lodge a support ticket first by sending us an email.

